

FN Key combination Function list

WIN:	MAC:	WIN/MAC:
FN+ESC Reset	FN+E7 Pause playback	FN+ESC Reset
FN+F1 Multimedia	FN+E8 CD Stop	FN+F1 F1
FN+F2 Volume ↓	FN+F9 Email	FN+F2 F2
FN+F3 Volume ↑	FN+E10 IE	FN+F3 F3
FN+F4 Volume mute	FN+F11 My Computer	FN+F4 F4
FN+F5 Last song	FN+F12 Calculator	FN+F5 F4
FN+F6 Next song		FN+F6 F6
		FN+E7 F7
		FN+E8 F8
		FN+E9 F9
		FN+E10 F10
		FN+E11 F11
		FN+E12 F12
		FN+ENTER
		FN+, Light mode switch
		FN+< Monochrome light switch
		FN+↑ Backlight brightness ↑
		FN+↓ Backlight brightness ↓
		FN+← Backlight speed reduction
		FN+→ Backlight speed plus
		FN+Y Partsc
		FN+U Scrlk
		FN+H Pause
		FN+J Ins
		FN+N Home
		FN+M End



02

Keyboard connection


Bluetooth mode: Press and hold the FN+1/2/3 key combination for 3S to make the keyboard enter pairing mode, the 1/2/3 indicator flashes quickly, and the 1/2/3 indicator stays on for 3S after connecting to the device, if not connected device, lights off, keyboard goes to sleep.



2.4G Mode: Press and hold the FN+4 key combination for 3S to make the keyboard enter 2.4G mode, the indicator light flashes quickly, insert the 2.4G dongle, exit the pairing after successful pairing, and exit the pairing mode after 30s if the paired device is not found, the indicator light is off, the keyboard go to sleep.



Wired mode: Press and hold the FN+5 key combination for 3S to make the keyboard enter wired mode.



03

CoolKiller

Model:CK75

Keyboard lighting settings



- FN+, : Keyboard lighting mode change.
- FN+< : Monochrome light switch
- FN+Enter: Switch backlight
- FN+↑ : Backlight brightness ↑
- FN+↓ : Backlight brightness ↓
- FN+← : Backlight speed reduction
- FN+→ : Backlight speed plus

01