



ClearSaver™ Channel Protector Ticket Molding

The ClearSaver™ Channel Protector Ticket Molding is designed to clip on to most C-channel shelving and the concave window hugs the channel protecting either a plain paper ticket or planogram strip. The window also helps protect the shelf from adhesive residue due to repeated use of adhesive tickets.



ClearSaver™ profile closed and open

Features

- Back leg clips under wide range of C-channel shelving types with secure fit
- Secures and protects paper tickets in C-channel
- Plastic window protects shelf edge from adhesive ticket residue
- Groove along the top to accommodate clip-in sign holders
- Easily pull molding open to replace price tickets

Code	Description	Color	Pack
262T-106920	ClearSaver™ Channel Protector Ticket Molding 1.25" H x 47.625" L	CL	100

*Contact us for custom length options



Toll-Free North America 1.800.661.5547

Kost Klip Manufacturing Ltd. | www.kostklip.com | sales@kostklip.com

262T_ClearSaver_Product and Installation Sheet_110918 | Printed in Canada

262T | INSTALLATION GUIDE

- 1** Press groove of ClearSaver™ against the bottom lip of the C-channel and snap along the length of the shelf.



- 2** Use the CV Tool to open the window to place or remove tickets behind the ClearSaver™.



- 3** Clip-in sign holders and accessories can be easily clipped over the ClearSaver™ once installed.



- 4** To remove ClearSaver™, reach under and pull off along the length of the shelf.



kostklip[®]
LIFE AT THE SHELF EDGE

Toll-Free North America 1.800.661.5547

Kost Klip Manufacturing Ltd. | www.kostklip.com | sales@kostklip.com

262T_ClearSaver_Product and Installation Sheet_110918 | Printed in Canada