




ECOFLOW

EcoFlow Wave 2 Add-on Battery QUICK START GUIDE



For details, please scan the QR code
or visit www.ecoflow.com/wave-2-add-on-battery

01



EN

1. Add-on battery socket
2. Unlock button
3. USB-C output port
4. USB-A output port
5. Indicator light
6. Power button

ES

1. Toma de batería adicional
2. Botón de desbloqueo
3. Puerto de salida USB-C
4. Puerto de salida USB-A
5. Luz indicadora
6. Botón de encendido

JP

1. バッテリーバック接続ポート
2. ロック解除ボタン
3. USB-C出力ポート
4. USB-A出力ポート
5. 表示灯
6. 電源ボタン

DE

1. Zusatzbatterie-Anschluss
2. Entriegelungsschalter
3. USB-C-Ausgangsanschluss
4. USB-A-Ausgangsanschluss
5. Anzeigeleuchte
6. Netzschalter

PT

1. Soquete para bateria complementar
2. Botão de destravamento
3. Porta de saída USB-C
4. Porta de saída USB-A
5. Luz indicadora
6. Botão liga/desliga

KR

1. 추가 배터리 소켓
2. 잠금 해제 버튼
3. USB-C 출력 포트
4. USB-A 출력 포트
5. 표시등
6. 전원 버튼

FR

1. Prise de batterie supplémentaire
2. Bouton de déverrouillage
3. Port de sortie USB-C
4. Port de sortie USB-A
5. Voyant lumineux
6. Bouton d'alimentation

NL

1. Poort voor extra accu
2. Ontgrendelknop
3. USB-C-uitgang
4. USB-A-uitgang
5. Indicatielampje
6. Aan-uitknop

CHS

1. 加电包插座
2. 解锁扣
3. USB-C输出端口
4. USB-A输出端口
5. 指示灯
6. 电源键

IT

1. Presa batteria aggiuntiva
2. Pulsante di sbloccaggio
3. Porta di uscita USB-C
4. Porta di uscita USB-A
5. Indicatore luminoso
6. Pulsante di accensione

RU

1. Дополнительный аккумуляторный отсек
2. Кнопка разблокировки
3. Выходной разъем USB-C
4. Выходной разъем USB-A
5. Индикатор
6. Кнопка питания

AR


1. مقبس البطارية الإضافية
2. زر الفتح
3. منفذ USB-C مخرج
4. منفذ USB-A مخرج
5. ضوء المؤشر
6. زر التشغيل

ECOFLOW




Raccolta carta


02



03



04



05

