







































84A-056






Please read these instructions and warranty information carefully before use and keep them properly for future reference.

ASSEMBLY INSTRUCTION


# PARTS

A	1			Q	2			
B	1			R	2			
C	1			S	2			
D	1			T	2			
E	2			U	1			
F	2							
G	1			V <sub>1</sub>	1			
H	4			V <sub>2</sub>	1			
I	1			W	4			
J	1			X1	6	 M8X50		
K	1			X2	12	 M6X20		
L	2			X3	4	 M6X30		
				X4	8	 M6X35		
M	2	Right	1			X5	4	 M8X50
		Left	1			X6	8	 M6X45
N	1			Z	40	 M8		
				Z1	2			
O	1			Y	4			
P	4			BB	1			
					1			







3




5




4




6




7



9



8



10