oneisall

Pet Grooming Clippers


Model:DTJ-001



User Manual

Any problems you have, please contact us: support@oneisall.com

Part name




Accessory name





Charaina/Plugaina

- 1.Confirm that the machine is turned off, and plug the USB cable into the 5V1A adapter (desktop/mobile power supply and other power supplies with USB interface) to charge the charging indicator flashes.
- 2. The display screen will show the charging status. After full charge, pull out the charaina cable.



Charging instructions

- 1. Please charge the pet clipper for 3 hours the first time use. After 3 to 4 times of full charge and discharge, the battery capacity will reach the best state.
- 2. The best ambient temperature for charging is between 5°C and 40°C.



♠ NOTE

- Pet hair clipper wireless use.
- In the case of no power, the pet hair clipper can be connected directly to the charger for cable operation.


LED Screen Display

LOW HIGH



- Battery percentage display(1%-100%)
- 1 Speed 5500rpm white light is on
- 2 Speed 7000rpm orange light is on
- When orange light is on means you need dripping oil, the light will flash 15 seconds

How to use



3. Install the guide comb as your needs



Cutter head disassemble

Trun off the switch, press the cutter head with your thumb, and push it out in the direction as pic.








⚠ NOTE

To avoid the cutter head falling, please hold the cutter head during disassembly.

Cutter head installation:

Put the cutter head connection A into the body clamp slot B



After aligning, press the cutter head back firmly until you hear a "click"



Cutter head clean:

Use a cleaning brush to remove the hair crumbs stuck on the cutter head.



Cutter head maintenance:

Apply 1-2 drops of lubricant oil into the 5 positions of the cutter head as shown Fig.



After dripping oil, press and hold the movable tool holder to move back and forth to make the lubricating oil evenly lubricate the tool head.

Product Specification

Product name	Pet clipper
Model	DTJ-001
Charger	Input: 5V=1A
Rechargeable battery	2000mAh
Battery type	Li-ion rechargeable
Charge time	3 hours
Operating time	3.5 hours

After-sales Service

Problem	Problem Causes	Solution
The product heats up during use	Internal parts of the machine have debris	Please remove the blade. Wash and oil.
		If the problem cannot be solved, please contact support@oneisall.com
Does not work	The battery is broken	Please contact the Email: support@oneisall.com
Can't charge	The charging environment temperature is too high or too low	Charging in an environment in 40°C or 50°C
	The charging cable is broken	Please contact the Email: support@oneisall.com

Problem	Problem Causes	Solution
Suggestions for using clipper	I	1.Wash and dry the pet first. 2.Trim the long hair with scissors and comb
Can I use it when charging	1	Yes, clipper can be used with cord or cordless
Clogging pet hair	Blade blunt	Apply a little oil on the cutter head for maintenance
limit comb damaged	1	Please contact the Email: support@oneisall.com
limit comb constantly falling off	Incorrect installation	Please contact the Email: support@oneisall.com

oneisall

Any problems you have, please contact us: support@oneisall.com

