

Sewing Machine Feet

CHEAT SHEET



ZIGZAG OR ALL PURPOSE

This is a versatile foot that can be used with most fabrics and stitches.



OVERCAST/OVERLOCK

This is used to lock the seam, to mimic an overlock or a serger seam.




ZIPPER

This is used to insert a zipper.



BLIND HEM

This is used to hem garments like pants or curtains.




BUTTONHOLE

This is used to add a buttonhole, it can adjust based on the button size.



QUILTING

This is used for free motion quilting, and for darning.



ROLLED HEM

This is used to make a rolled hem, it can come with different widths.




QUARTER INCH

This is used to make a 1/4 inch seam allowance. They come with or without a guide.



INVISIBLE ZIPPER

This is used to insert an invisible zipper.



WALKING

This is used when quilting, sewing slippery fabric, or layers.