






# Pine Raised Trough Planter Assembly

	A - Side Sections x2	<p>Tools Required</p> <ul style="list-style-type: none"><li>● Cross Head Screwdriver</li><li>● Rubber/Soft Mallet</li></ul> <p><u>Please Note</u></p> <p>Number of 'Feet Parts' will vary depending on size of planter</p>
	B - End Sections x2	
	C - Feet	
	D - Base x1	
	Fixing Screws	

# Pine Raised Trough Planter Assembly

**Step 1:** Place 1st side section into end section, you may need to tap it in place with a mallet



**Step 2:** Locate the pre-drilled holes on both sections and fix in place with supplied screws




# Pine Raised Trough Planter Assembly

**Step 3:** Place 2nd end section onto 1st side section and attach with screws as in step 2.



**Step 4:** Now do the same with the final side section, you may need to tap it into place gently before fixing with screws.



# Pine Raised Trough Planter Assembly

**Step 5:** Turn the planter upside down and attach the feet using 2 screws per foot.



**Step 6:** Turn the planter over again so that it's upright and place the base section inside.



# Pine Raised Trough Planter Assembly

## Your Planter is now complete!

- We recommend using a liner inside the planter before adding your compost and plants, this will help to prolong its life and protect it from rot.
- You can also use a wood preservative of your choice, or paint it in your preferred colour.

