



# Steering Wheel Remote Installation Guide for the M9900CDS Receiver


1. Attach the remote holder base to the inside edge of the steering wheel using the strap supplied as shown in Figure 1. Make certain that the arrow engraved into the remote holder base is facing the driver. Secure one end of the strap to the outer edge of the remote holder base as shown in Figure 1. Pull the strap snug around the steering wheel and secure the strap to the cleats on the holder base. Some stretching of the strap will be required but do not over-stretch the strap.




2. Cut the extra portion of the strap near the center of the remote holder as shown in Figure 2.



3. Attach the remote holder cover loosely to the holder base using the screws supplied as shown in Figure 3. Adjust/rotate the remote holder assembly to the desired position and tighten the screws.




4. Attach the Remote Control unit to the Holder as shown in Figure 4 until a "click" sound is heard. To remove the Remote Control unit from the Holder, press the Ribbed Switch toward the steering wheel, then slide the Remote Control off the Holder.






### WARNINGS


- Do not install this Steering Wheel Remote in a location where it prevents the proper operation of safety devices such as air bags.
- Do not install this unit in a location where it prevents the proper operation of the steering wheel or gearshift lever.
- Do not install this Steering Wheel Remote in a location that may obstruct the driver's view.
- Do not install this unit to the outer edge of the steering wheel, it may interfere with driver's ability to steer the vehicle which could result in a traffic accident. Always attach this unit to the inside edge of the steering wheel as shown in Figure 5.
- Mount this unit securely to the steering wheel. If this unit is loose, it may interfere with driver's ability to properly steer the vehicle.
- Installation of this unit requires special skills and experience and should be entrusted to a trained technician.
- Install this unit using only the parts supplied.
  If other parts are used the unit may be
  damaged or could dismount itself, which
  could result in a traffic accident.
- Only install this unit as illustrated in this manual.







# Steering Wheel Remote Functions and Controls for the M9900CDS Receiver



#### 2. Volume Controls:

Press the "Level +" button to increase the volume level.

Press the "Level –" button to decrease the volume level.

#### 3. Tune/Seek Buttons:

#### Radio Mode:

**Manual Tuning:** Push one of the SEEK buttons and hold until "MANUAL" appears in the display then release button. Push the SEEK buttons again left or right until the desired radio station appears in the display.

**Seek Tuning:** Push one of the SEEK buttons and release. The tuner will scan to the next strong station and stop.

**Sirius Mode:** Push either SEEK button to change to the next the Sirius radio station.

**CD and CD Changer Mode:** Push either SEEK button to change the CD track on the CD that is playing.

#### 4. Multi-Function Button:

**Radio Mode:** Push to recall preset radio station #1.

**CD Mode:** Push to enter CD track memory mode (see M9900CDS Manual for more information, pages 6-7).

**CD Changer Mode:** Push to change to a lower disc in the CD changer.

**Sirius Satellite Radio Mode:** Push to recall preset radio station #1.

#### 5. Multi-Function Button #2:

**Radio Mode:** Push to recall preset radio station #2.

**CD Mode:** Push to play programmed CD tracks (see M9900CDS Manual for more information, pages 6-7).

**CD Changer Mode:** Push to change to a higher disc in the CD changer.

**Sirius Satellite Radio Mode:** Push and release when recalling preset radio station #2.

10. Weather Band Radio Button: Push to instantly access the weather band radio. Push mode to return to previous source.

#### 14. Mute Button (CD Play/Pause) Button:

Radio and Sirius Satellite Radio Mode: Push to mute volume level. Push again to restore volume.


**CD and CD Changer Mode:** Push to pause disc play, push again to resume play.

17. Mode Button: Push to change the play source: Radio, Sirius Satellite Radio, CD, CD Changer or Auxiliary Sources.


## **Installing a New Battery**

**Note:** Replace with battery number CR2032 only.

- **1.** While pressing the button on the steering wheel mount, slide the remote control forward.
- 2. Slide battery cover off the remote control.



- **3.** Remove the battery from the remote control.
- Properly insert a new battery into remote. Note: The positive side on the battery is facing up.
- Replace cover and slide the remote back onto the steering wheel mount until it clicks into place.



© Copyright 2005 Magnadyne Corporation M9900-SWR3-IMUM 5-19-05 Rev. C