
CONTENTS

Updated 17DEC2019



SAFETY INFORMATION

Suitable for dry, indoor use only.


Maximum ambient temperature: 25°C

If the external flexible cable or cord of this luminare is damaged, it shall be exclusively replaced by Roll & Hill or Roll & Hill's service agent or a similarly qualified person in order to avoid hazard. The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

Note: Please contact a licensed electrician for installation.


01. Gently remove the base (A) out from the opened box. Do not grab by the extrusion (B) but only by the base.

Sit the base assembly upright on the ground.




Note: Please contact a licensed electrician for installation.

02. Assemble the fitter (C) and extrusion (B) as shown below. A rubber mallet may be cautiously used to force the fitter in the extrusion.



Note: Please contact a licensed electrician for installation.


03. Gently lay the fixture down. Plug in the fixture to test the LED tape (D) (See POWER ADAPTOR INSTALLATION section). While the tape is still on and starting from the bottom end, gently feed the tape in the extrusion using the roller. To achieve best result, roll one side of the tape first, then proceed with the other. Leave the plug in during the entire process, this will help to prevent any visible waves and irregularities during the tape feeding step.



Note: Please contact a licensed electrician for installation.


04. Unplug the fixture. With a pair of sharp scissors, cut the extra LED tape so it is flush with the metal extrusion.

Replug the fixture to check the result. After cutting, a small amount of light may be lost at the end tip.




Note: Please contact a licensed electrician for installation.

05. Finish the assembly by adding the cap on top of the last extrusion.



POLE 01 | POWER ADAPTOR INSTALLATION

1. Find the suitable driver adapter for your country's outlet type.



- 2. Slide driver adapter (A) into USB driver (B) until it clicks into place.
- 3. To remove a driver adapter, press on the flexible tab on the adapter (A) and slide it out of the USB driver (B).

