Instruction



To ensure the safety of your baby, please read and follow the instruction carefully before using. Keep the instruction for future reference.

WARNING:

- Never leave your child unattended.
- This product is not suitable forrunning or skating.
- Ensure that all the locking devices are engaged before use. Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use.
- To avoid injury ensure that your child is kept away when unfolding and folding this product.
- Do not let your child play with this product.
- Always use the restraint system.
- Use the harness buckles as soon as your child can sit unaided.
- This seat unit is not suitable for children under 6 months.
- For new born babies, the sleeping basket shall be adjusted to the most reclined position.
- Use the cushion in sleep position. In sleep position, the maximum thickness for the cushion is 5cm.
- Any load attached to the handle and/or the back of the backrest and/or on the sides of the vehicle will affect the stability of the vehicle.
- The vehicle shall be used only for up to 1 baby at a time.
- Only replacement parts supplied or recommended by the manufacture/distributor shall be used.

Maintenance

For safety, please inspect and maintain the stroller regularly. Check for worn parts regularly. Please replace worn parts if necessary. When replacing them, please follow the instructions carefully to avoid unexpected damage.

Attention

Avoid placing object on top of the stroller.

Avoid the use of non-genuine parts or other accessories. The canopy cannot be machine washed--hand wash only. Do not wash the canopy too hard.

Dry the canopy in the shade after washing, avoid sun exposure.

Basic Equipment List:

★ Please check all parts carefully to make sure if there is any missing or damaged parts before installation. For any missing or damaged parts, please contact our online customer service to get the help needed. In order to guarantee the service life of the product, please use it under the guidance of this instruction.



★ Children are not allowed to fold, assemble or disassemble the stroller. The product must be assembled by adults.

1.Pull the main handle up until the sound of click is heard ,which showed the frame is unfolded correctly.



2.Assemble and Disassemble the Front Wheel Pull the front part of the frame up and insert the metal bar into the front wheel.







Assemble the front wheel

Press the button to release the front wheel

Please ensure that the front wheel is properly assembled by pulling it down before use.

3.Assemble and Disassemble the Rear Wheel Pull up the back part of the frame and insert the metal bar







Assemble the rear wheel

Finish assembling Slide upward the device to disassemble the rear wheel

Please ensure that the rear wheel is properly assembled by pulling it outward before use.

4. Assemble and Disassemble the Canopy

Insert the clamp on both sides of the canopy into the slot of the seat/sleeping basket. Then pull up the zipper.







Finished



Insert the canopy

Zip up

Pull out the canopy

Safety Principal

Important-keep this instruction for future reference. Before using this product, please read the following instruction carefully.

1.The stroller must be assembled by adults, please keep your children away from the assembling process.

2.In seat position, always use the safety belt. Usage is shown in the 6th parts of this instruction.

3.In sleep position, use the mattress we provided to cover the safety belt. No additional mattress shall be used.

4.Pls be noted that the pram body and seat/sleep unit are only compatible with the chassis of the frame model.

5.This product is suitable for babies of 0-36 months under the weight of 15kg. Sleep mode is suitable for babies of 0-36 months; seat mode is suitable for babies of 6-36 months.

6.In seat mode, pls lock the harness attachment points as shown in the first part in the function display of the instruction.

7. This product is suitable for a child who cannot sit up

3.Folding instructions



Pull the folding lock up simultaneously.



Finish folding.



Press downward the product.



5.Assemble and Disassemble the Armrest

Insert the armrest into the slot to assemble it; press the button to disassemble it.




6.Assemble, Disassemble and Adjust the Seat/Sleeping Basket

Insert the clamp on both sides of the seat/sleeping basket into the slot of the frame to assemble it. Press the square button to disassemble it and press the round button to adjust the angle of it.





Press the round button to adjust the angle of the seat





Adjust the basket to the right angle and fasten the buckle

7.Usage and adjustment of the safety belt


To avoid accidently falling, please use the safety belt in seat position. The usage is shown in the following pictures.





Press the round button to unlock the safety belt.





Lock the shoulder belt as shown in the picture.

Function Display

Stretch the flexthe belt to adjust the length, which for your baby' s convenience

★ Do not move the adjustment seat while the baby is sitting in the seat

The shifting of the seat and sleeping basket status is accomplished by four safety clasps at the bottom, transforming the bottom four safety clasps into seat mode. Release the bottom safety buckle to sleep mode









Upper safety buckle

Mid safety buckle

Lower safety buckle

Down safety buckle

1.Braking function of the rear wheel

Step the pedal backwards to brake the stroller. Otherwise to release the brake.





Brake

Release brake

2.Six positions

The seat/sleeping basket can be adjusted in 6 different positions by pressing the two round buttons on both sides of the basket.







Seat forward lying

Seat forward reclining

Seat forward sitting







Seat backward recling Seat backward sitting