qwertykey







Functions of combination keys:

Fn+ F1 - Screen Brightness Down
Fn+ F2 - Screen Brightness Up
Fn+ F3 - Calculator
Fn+ F4 - My Computer
Fn+ F5 - Mail
Fn+ F6 - Browser
Fn+ ↑ - Backlit Brightness Down
Fn+ A - Win Mode
Fn+ F7 - Media Prev Track
Fn+ F8 - Media Play/Pause
Fn+ F9 - Media Next Track
Fn+ F9 - Media Next Track
Fn+ F10 - Molume Mute
Fn+ F11 - Volume Down
Fn+ F12 - Volume Up

Fn+ ↓ - Backlit Brightness Up Fn+ S - Mac Mode
Fn+ ← - Backlit Speed Down Fn+ Win Lock/Unlock
Fn+ → - Backlit Speed Down Fn+ Esc (5Sec) - Reset the Keyboard

Fn+ Back Space - Backlit On/Off

Fn+ Del - Backlit Effects Switch