

THE MARMOSET ASSEMBLY INSTRUCTIONS

#### **CONTENTS**

Warnings	e 1
Load Rating	je 3
Dimensions	e 4
Assembly Tips	e 5
Inventory	e 7
Assembly Instructions	e 9
Ladder Bar Assembly	e 9
Leg Assembly	e 12
Twirly Whirly Bar Assembly	e 16
Main Monkey Bar Assembly	e 18
Swing Bar Assembly	e 20
Load Twirly Whirly Bars	je 24
Maintenance	ie 26

#### WARNING

PLEASE CAREFULLY READ ALL INFORMATION CONTAINED IN THIS ASSEMBLY MANUAL BEFORE YOU INSTALL AND USE YOUR FUNKY MONKEY BARS®.


#### **SAFETY NOTICE**

- 1. Any person handling or using the Funky Monkey Bars® products must follow the instructions as described in this document. The person in charge of assembling and using the equipment must ensure that the recommendations for use given in this document are seen by all users.
- 2. Only use the Funky Monkey Bars® after they have been fully assembled and after checking that the fittings are tightened properly (refer to page 5 Correct Tightening Method).
- 3. DO NOT install your Funky Monkey Bars® over concrete, asphalt, packed earth, wood decking or any other hard surface. A fall onto a hard surface can result in serious injury or death.
- 4. Inspect all grub screws, bolts and nuts at the beginning of each play session to ensure your Funky Monkey Bars® are tight and secure.
- 5. Ensure all tubes are fully inserted into fittings until you hear the magic "CLUNK" sound.
- 6. Ensure your Funky Monkey Bars® are properly secure at ALL times. Pegs are in place and inserted fully into the ground.
- 7. DO NOT exceed the maximum load/weight limit as recommended by Funky Monkey Bars®.
- 8. Children should be supervised by an adult at all times.
- 9. Installing a gym/crash mat under the fall zone area of your Funky Monkey Bars® would be recommended for children learning this new skill. This will reduce the chance of injury and build the child's confidence while they build strength and master the skill.
- 10. Ensure you have thoroughly read your assembly and installation instructions and viewed our on-line installation videos at https://www.funkymonkeybars.com/blogs/installation-maintenance-videos
- 11. DO NOT climb, sit or stand on top of the monkey bar (horizontal ladder) section.
- 12. DO NOT jump from the top of any section of the monkey bar.
- 13. DO NOT use your Funky Monkey Bars ${\tt B}$  when wet as the steel will be slippery.
- 14. DO NOT attach items to your frame that are not designed specifically to be used with Funky Monkey Bars®, especially lower quality products that have not been approved by Funky Monkey Bars®.
- 15. Ensure the height of your Funky Monkey Bars® (horizontal ladder) are set at a level that is age appropriate.
- 16. DO NOT install your Funky Monkey Bars® over or near objects that could interfere with users in an unsafe way. Maintain a clear area around your Funky Monkey Bars®.
- 17. DO NOT use your Funky Monkey Bars® while under the influence of drugs and alcohol.
- 18. Wear clothing free of drawstrings, hooks, loops or anything that could get caught while using your Funky Monkey Bars® and result in entanglement and/or strangulation.


#### **ASSEMBLY**

- 1. Keep small children away from the Funky Monkey Bars® during assembly.
- 2. Do not attempt to use the Funky Monkey Bars® until it is completely assembled and every fitting is tight and secured.
- 3. Installation typically takes 3-4 hours to complete. Two people are recommended for assembly.
- 4. Ensure all fittings are tightened to the correct tightening method as described on page 5.
- 5. Assembly should be carried out on clean, dry, level surface


Please refer to the video section on the Funky Monkey Bars® website for more handy tips and assembly instructions at http://www.funkymonkeybars.com/pages/videos







Heavy items!



Work on flat level surface.

#### LOCATION

- 1. A safe fall zone around your Funky Monkey Bars® is essential. A minimum distance of 1.5m to 2m (5 ft to 6.5ft) is recommended around the elevated hanging points of your Funky Monkey Bars®.
- 2. Place your Funky Monkey Bars® on level ground, away from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires and remove any obstructions beneath your Funky Monkey Bars®.
- 3. Ensure your Funky Monkey Bars® are positioned away from retaining walls, pool fences, structures and other play equipment. Maintain a clear space around the whole perimeter of your Funky Monkey Bars®.
- 4. Place your Funky Monkey Bars® on the most level surface available.

#### **MAINTENANCE**

- 1. At the beginning of each heavy play session we recommend the following maintenance processes be performed on your Funky Monkey Bars®:
  - Tighten all bolts, grub screws and applicable hardware (as per page 5)
  - Lubricate all metallic moving parts as per instructions (flying fox, swing hooks etc)
  - Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
  - Check all moving parts including swing seats, shackels, snap hooks, chains and trolleys for wear, rust, or other deterioration. Replace as needed.
- 2. Twice a month during play season we would recommend the following maintenance processes be performed on your Funky Monkey Bars®:
  - Tighten all connections and hardware
  - Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
- 3. Once a month during play season we would recommend the following maintenance processes be performed on your Funky Monkey Bars®:
  - Lubricate all metallic moving parts as per instructions (flying fox, swing hooks etc). If swings start to squeek then lubricate swing hooks.
  - Check all moving parts including swing seats, ropes, chains and trolleys for wear, rust, or other deterioration. Replace as needed.
  - Owners shall be responsible for maintaining the legibility of any warning labels.

For additional information concerning your Funky Monkey Bars®, please contact our customer service team or check our website for any important updates. Phone - 1300 912 198 or www.funkymonkeybars.com

### **QUALITY & INDEPENDENT TESTING**

At Funky Monkey Bars® we take the quality of our designs and safety very seriously. All Funky Monkey Bars® frames go through a stringent, independent structural testing process prior to being made available for release to our customers.

Our frames are designed within the parameters of the Australian Standard for Playground Equipment AS4685.1:2014.

The structural integrity of our frames has been tested for performance through a combination of engineering calculations and physical testing. The tests have been performed by independent, certified structural engineers in accordance with Australian Standard for Playground Equipment AS4685.1:2014 and European Standards EN1176-1:2008.

The independent testing conducted on The Marmoset certified the frame to a load rating of 1620kgs or 27 users.

LOAD TESTING CERTIFICATION						
DATE OF TEST	MODEL	NUMBER OF USERS	USER LOAD (KG)	LOAD RATING (KG)		
18 April 2019	Marmoset	27	60	1620		

I hereby confirm all testing was undertaken in accordance with Physical Testing of Structural Integrity requirements of AS 4685.1: 2014 App C / EN 1176-1:2008° except where noted below;

**COMMENTS:** 

**DATE:** 27 May 2019

N/A

 APPROVED BY:
 Funky Monkey Bars®
 WITNESSED BY:
 Independent Engineer


Wengy.

**DATE:** 27 May 2019

APPROVED


# FUNKY MONKEY BARS® THE MARMOSET OVERALL DIMENSIONS

A mimimum of 2.0 Metres clear fall zone is recommended around the elevated hanging points of your Funky Monkey Bars®.




### CORRECT INSERTION INTO FITTINGS - (INDICATIVE DIAGRAM SHOWN)


All tubes must be fully inserted until contact is made with adjoining tube.








### CORRECT TIGHTENING METHOD OF GRUB SCREWS - (INDICATIVE DIAGRAM SHOWN)



 With long end of allen key, hand tighten grub screw as much as possible.






2. Using other end of the allen key do one full 360 degree turn as a minimum, use muscles!




### CORRECT TIGHTENING METHOD OF RUNG BOLTS - (INDICATIVE DIAGRAM SHOWN)




 With long end of allen key, hand tighten bolt hard up against washer and outside of tube. Hold rung to avoid rotation.






2. Using short end of the allen key fully tighten, approximately 3-4 full turns .








### **INVENTORY**

### **TOOLS REQUIRED FOR INSTALLATION**



### **TUBES**

**26x**Rung Tube
25Dia. x 850mm

**8x** 50Dia. x 900mm Twirly Tube 0

1x 50Dia. x 1040mm Cargo Tube 0

**2x** 50Dia. x 2300mm Swing Leg Tube


**2x** 50Dia. x 2950mm

Double Swing Tube (


8x 50Dia. x 2300mm Adj. Leg Tube 0 9

4x 50Dia. x 2950mm Ladder Tube 0 0 0 0 0 0 0 0


### **FITTINGS**



18x Short Tee D-101




**8x** Elbow D-125




14x Base Plate D-131

### INVENTORY (CONTINUED)

### **HARDWARE**



**54x** M10 Bolt



108x Rung Insert

Height Sticker



**54x** Washer




108x M10 Hex Nut




Plastic End Cap



1x Manufacture Sticker



### **COMPONENTS (ACCESSORIES IF APPLICABLE)**




One of the best things about a Funky Monkey Bar is the ability to add new equipment and accessories as your child and family grows. You can swap or add accessories to your existing frame, or add extra frames that will give you more versatility to attach equipment. Check out what we've got in store now at...


WWW.FUNKYMONKEYBARS.COM

# **ASSEMBLY INSTRUCTIONS - LADDER BAR ASSEMBLY**

# RUNG ASSEMBLY (x26)





1. Assemble plastic rung inserts as shown above.




2. Push inserts into both ends of all rungs.


### **9** MONKEY BAR LADDER ASSEMBLY






















# SET LADDER BAR HEIGHT.






REPEAT STEPS 7-13 FOR 3 MORE SETS OF LEGS.


SAME PROCEDURE BUT WITHOUT CARGO NET AND DIFFERENT LOCATION/DELETION OF ADDITIONAL SHORT TEE (A).

SEE BELOW FOR DESIRED RESULT.

# 15 LEG ASSEMBLY x 4.




### NOTE: SET TOP SHORT TEES ON LEGS 3 & 4 AT A DIFFERENT HEIGHT TO 1 & 3, TO ACCOMODATE VARIOUS SKILL LEVELS.




### **ASSEMBLY INSTRUCTIONS - TWIRLY WHIRLY BAR ASSEMBLY**

#### 16 **ASSEMBLE VERTICAL TWIRLY TUBE**





Tighten all grub screws.



#### **17** ATTACH HORIZONTAL TWIRLY TUBE


Fully insert twirly tube then firmly tighten all grub screws.







18 REPEAT STEPS 16 - 17 FOR 3 MORE TWIRLY WHIRLY BARS.




20

FLIP LEGS 1 & 2 OVER




For the following step the legs should be flipped over & attached one at a time.








- 1. Attach first set of legs 1- tighten all grub screws.
- 2. Attach second set of legs  $\widehat{\mbox{\em 2}}$  tighten all grub screws.




# 22 FLIP ASSEMBLY OVER



CRITICAL: ENSURE YOUR FRAME IS 100% SQUARE AND LEVEL (AS PER PAGE 6)
BEFORE MOVING ONTO THE REST OF THE ASSEMBLY

# 23 SECURE TO GROUND



REPEAT STEPS 20-22 FOR 1 MORE COMPLETE MAIN MONKEY BAR ASSEMBLY.

SAME PROCEDURE BUT USING LEGS 3 & 4 FROM STEP 15

SEE BELOW FOR DESIRED RESULT.


# **25** MAIN MONKEY BAR ASSEMBLY X2.





Locate and align the new main monkey bar assembly along side the first one (on the opposite side to the cargo net), at a distance of approximately 105cm apart.


Do not peg down second assembly at this stage.




# **26** SWING BAR ASSEMBLY X2.





Slide on all fittings and fully tighten elbow grub screws Leave short tees and swing hooks loose for assembly adjustment.














## 29 ATTACH CARGO TUBE








3. Thread in bottom cargo tube between cargo net hoops & fully engage into short tees.



4. Get second person to stand on tube to make cargo net taught, then fully tighten grub screws.



# 30 CHECK ALL FITTING GRUB SCREWS ARE FULLY TIGHTENED










- 1. Ensure frame is square and level.
- 2. Firmly tighten all grub screws and bolts.

#### 31 **SECURE TO GROUND**




- Check level and square.
   Hammer in all remaining pegs x6.







#### 32 ATTACH TWIRLY WHIRLY BARS X4



# **33** LOAD YOUR TWIRLY WHIRLY BARS X4




To reduce movement in your frame load your twirly whirly bars as follows.




K

2. Loosen the grub screw fixing the short tee to the swing leg.



 Ensure twirly whirly is level and square & swing leg is pegged down. 3. Pull upwards on the twirly whirly bar to make a slight angle. (Half a bubble off center on the level)



+ 360°

**6**. Tighten grub screw fixing the short tee to the swing leg tube. Apply to all twirly whirlys.

**5**. Push down on the twirly whirly bar until horizontal bar is level.


REFER TO VIDEO SECTION OF WEBSITE HTTP://WWW.FUNKYMONKEYBARS.COM/PAGES/VIDEOS

### ATTACH ACCESSORIES (IF APPLICABLE)



Attach new accesories in desired position (if applicable) and tighten swing hook bolts with rachet. Marmoset supplied accessory: (sling swing shown) Marmoset supplied accessory: (rubber swing shown) Marmoset supplied accessory: (trapeze shown)

#### 35 **FINAL CHECKS**








- Ensure frame is square and level.
   Firmly tighten all grub screws and bolts.
   All base plates are pegged down.



Apply your manufacturing sticker to a leg tube.

# 36 MAINTENANCE.



At the beginning of each heavy play session (especially a party) and twice a month during play season ensure;

- 1. Tighten all hardware grub screws, nuts and bolts.
- 2. Pegs are in place and fully secure.
- 3. Lubricate all metallic moving parts with WD40 or Vasaline (trolley and swing hooks.)
- 4. Ensure your frame is level and square.

FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH.

# FOR MORE INFORMATION AND ASSEMBLY TIPS PLEASE REFER TO OUR WEBSITE VIDEO INSTRUCTION SECTION AT HTTP://WWW.FUNKYMONKEYBARS.COM/PAGES/VIDEOS

37 HAVE FUN











ABN 72 164 496 520

1300 912 198

info@funkymonkeybars.com www. funkymonkeybars. com

9 Cutting Way, **Yangebup** WA 6164





