

THE ORIGINAL ASSEMBLY INSTRUCTIONS

CONTENTS

Warnir	ngs																	Page 1
Load I	Rating																	Page 3
Dimer	nsions																	Page 4
Assem	ably Tips																	Page 5
Invent	ory				 						 				 			Page 7
Assem	ably Instructions																	Page 9
	Ladder Bar Asse	embly																Page 9
	Leg Assembly							 										Page 11
	Twirly Whirly Bar	Assem	bly															Page 15
	Main Monkey B	ar Asse	mbly	/				 										Page 16
Load 1	Twirly Whirly Bars										 				 			Page 19
Sticke	r Placement Gui	de							 							 		Page 20
Mainte	enance																	Page 22

WARNING

PLEASE CAREFULLY READ ALL INFORMATION CONTAINED IN THIS ASSEMBLY MANUAL BEFORE YOU INSTALL AND USE YOUR FUNKY MONKEY BARS®.


SAFETY NOTICE

- 1. Any person handling or using the Funky Monkey Bars® products must follow the instructions as described in this document. The person in charge of assembling and using the equipment must ensure that the recommendations for use given in this document are seen by all users.
- 2. Only use the Funky Monkey Bars® after they have been fully assembled and after checking that the fittings are tightened properly (refer to page 5 Correct Tightening Method).
- 3. DO NOT install your Funky Monkey Bars® over concrete, asphalt, packed earth, wood decking or any other hard surface. A fall onto a hard surface can result in serious injury or death.
- 4. Inspect all grub screws, bolts and nuts at the beginning of each play session to ensure your Funky Monkey Bars® are tight and secure.
- 5. Ensure all tubes are fully inserted into fittings until you hear the magic "CLUNK" sound.
- 6. Ensure your Funky Monkey Bars® are properly secure at ALL times. Pegs are in place and inserted fully into the ground.
- 7. DO NOT exceed the maximum load/weight limit as recommended by Funky Monkey Bars®.
- 8. Children should be supervised by an adult at all times.
- 9. Installing a gym/crash mat under the fall zone area of your Funky Monkey Bars® would be recommended for children learning this new skill. This will reduce the chance of injury and build the child's confidence while they build strength and master the skill.
- 10. Ensure you have thoroughly read your assembly and installation instructions and viewed our on-line installation videos at https://www.funkymonkeybars.com/blogs/installation-maintenance-videos
- 11. DO NOT climb, sit or stand on top of the monkey bar (horizontal ladder) section.
- 12. DO NOT jump from the top of any section of the monkey bar.
- 13. DO NOT use your Funky Monkey Bars® when wet as the steel will be slippery.
- 14. DO NOT attach items to your frame that are not designed specifically to be used with Funky Monkey Bars®, especially lower quality products that have not been approved by Funky Monkey Bars®.
- 15. Ensure the height of your Funky Monkey Bars® (horizontal ladder) are set at a level that is age appropriate.
- 16. DO NOT install your Funky Monkey Bars® over or near objects that could interfere with users in an unsafe way. Maintain a clear area around your Funky Monkey Bars®.
- 17. DO NOT use your Funky Monkey Bars® while under the influence of drugs and alcohol.
- 18. Wear clothing free of drawstrings, hooks, loops or anything that could get caught while using your Funky Monkey Bars® and result in entanglement and/or strangulation.


ASSEMBLY

- 1. Keep small children away from the Funky Monkey Bars® during assembly.
- 2. Do not attempt to use the Funky Monkey Bars® until it is completely assembled and every fitting is tight and secured.
- 3. Installation typically takes 2-3 hours to complete. Two people are recommended for assembly.
- 4. Ensure all fittings are tightened to the correct tightening method as described on page 4.
- 5. Assembly should be carried out on clean, dry, level surface


Please refer to the video section on the Funky Monkey Bars® website for more handy tips and assembly instructions at http://www.funkymonkeybars.com/pages/videos







Heavy items!



Work on flat level surface.

LOCATION

- 1. A safe fall zone around your Funky Monkey Bars® is essential. A minimum distance of 1.5m to 2m (5 ft to 6.5ft) is recommended around the elevated hanging points of your Funky Monkey Bars®.
- 2. Place your Funky Monkey Bars® on level ground, away from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires and remove any obstructions beneath your Funky Monkey Bars®.
- 3. Ensure your Funky Monkey Bars® are positioned away from retaining walls, pool fences, structures and other play equipment. Maintain a clear space around the whole perimeter of your Funky Monkey Bars®.
- 4. Place your Funky Monkey Bars® on the most level surface available.

MAINTENANCE

- 1. At the beginning of each heavy play session we recommend the following maintenance processes be performed on your Funky Monkey Bars®:
 - Tighten all bolts, grub screws and applicable hardware (as per page 3)
 - Lubricate all metallic moving parts as per instructions (flying fox, swing hooks etc)
 - Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
 - Check all moving parts including swing seats, shackles, snap hooks, chains and trolleys for wear, rust, or other deterioration. Replace as needed.
- 2. Twice a month during play season we would recommend the following maintenance processes be performed on your Funky Monkey Bars®:
 - Tighten all connections and hardware
 - Check all protective coverings on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
- 3. Once a month during play season we would recommend the following maintenance processes be performed on your Funky Monkey Bars®:
 - Lubricate all metallic moving parts as per instructions (flying fox, swing hooks etc). If swings start to squeak then lubricate swing hooks.
 - Check all moving parts including swing seats, ropes, chains and trolleys for wear, rust, or other deterioration. Replace as needed.
 - Owners shall be responsible for maintaining the legibility of any warning labels.

For additional information concerning your Funky Monkey Bars®, please contact our customer service team or check our website for any important updates. Phone: 1300 912 198 or www.funkymonkeybars.com

QUALITY & INDEPENDENT TESTING

At Funky Monkey Bars® we take the quality of our designs and safety very seriously. All Funky Monkey Bars® frames go through a stringent, independent structural testing process prior to being made available for release to our customers.

Our frames are designed within the parameters of the Australian Standard for Playground Equipment AS4685.1:2014.

The structural integrity of our frames has been tested for performance through a combination of engineering calculations and physical testing. The tests have been performed by independent, certified structural engineers in accordance with Australian Standard for Playground Equipment AS4685.1:2014 and European Standards EN1176-1:2008.

The independent testing conducted on The Original certified the frame to a load rating of 486kgs or 7 users.

LOAD TESTING CERTIFICATION													
DATE OF TEST	MODEL	NUMBER OF USERS	USER LOAD (KG)	LOAD RATING (KG)									
October 2015	The Original	7	69.5	486									

I hereby confirm all testing was undertaken in accordance with Physical Testing of Structural Integrity requirements of AS 4685.1: 2014 App C / EN 1176-1:2008° except where noted below;

COMMENTS:

DATE: October 2015

N/A

 APPROVED BY:
 Funky Monkey Bars®
 WITNESSED BY:
 Independent Engineer


Mars bars


DATE: October 2015

APPROVED

FUNKY MONKEY BARS® THE ORIGINAL OVERALL DIMENSIONS

A minimum of 2.0 Metres clear fall zone is recommended around the elevated hanging points of your Funky Monkey Bars®.







SIDE VIEW (not to scale)

CORRECT INSERTION INTO FITTINGS - (INDICATIVE DIAGRAM SHOWN)


All tubes must be fully inserted until contact is made with adjoining tube.



Gap.




CORRECT TIGHTENING METHOD OF GRUB SCREWS - (INDICATIVE DIAGRAM SHOWN)



 With long end of allen key, hand tighten grub screw as much as possible.






2. Using other end of the allen key do one full 360 degree turn as a minimum, use muscles!




CORRECT TIGHTENING METHOD OF RUNG BOLTS - (INDICATIVE DIAGRAM SHOWN)



 With long end of allen key, hand tighten bolt hard up against washer and outside of tube. Hold rung to avoid rotation.






2. Using short end of the allen key fully tighten, approximately 3-4 full turns .








PLAN VIEW



Check assembly is 100% level, square & straight.

SIDE VIEW




If your frame is not straight or level remove pegs, loosen grub screws, re-adjust re-tighten and re-peg the frame.

INSTALLATION ON A SLOPE

If your frame is being installed on a slope ensure the monkey ladder bar is level. Either install at different heights on the legs or dig down at one end until level.


FIXING TYPICAL ORIENTATION - (INDICATIVE DRAWING SHOWN)

Unless otherwise stated all grub screws and fittings should face downwards and outwards. This will reduce weathering damage, help with assembly and ease of maintenance.



INVENTORY

TOOLS REQUIRED FOR INSTALLATION



TUBES

13x
Rung Tube

8x
Twirly Tube

4x
Adj. Leg Tube

25Dia. x 850mm

50Dia. x 900mm

0


2x

50Dia. x 2300mm

50Dia. x 2300mm


FITTINGS

Ladder Tube




INVENTORY (CONTINUED)

HARDWARE



27x M10 Bolt



54x Rung Insert



27x Washer



54x M10 Hex Nut



4x Plastic End Cap



1x Manufacture Sticker



Height Sticker


COMPONENTS (NOT APPLICABLE)

One of the best things about a Funky Monkey Bar is the ability to add new equipment and accessories as your child and family grows. You can swap or add accessories to your existing frame, or add extra frames that will give you more versatility to attach equipment. Check out what we've got in store now at...


WWW.FUNKYMONKEYBARS.COM

ASSEMBLY INSTRUCTIONS - LADDER BAR ASSEMBLY

RUNG ASSEMBLY (X13)





1. Assemble plastic rung inserts as shown above.





2. Push inserts into both ends of all rungs.


9 MONKEY BAR LADDER ASSEMBLY























10 APPLY HEIGHT STICKERS.




11 SET LADDER BAR HEIGHT.







REPEAT STEPS 5 -12 FOR SECOND PAIR OF LEGS.



15 ASSEMBLE VERTICAL TWIRLY TUBE





Tighten all grub screws.



16 ATTACH HORIZONTAL TWIRLY TUBE


Fully insert twirly tube then firmly tighten all grub screws.








17 REPEAT STEPS 15 -16 FOR 3 MORE TWIRLY WHIRLY BARS.



19 **FLIP LEGS OVER**




For the following step the the legs should be flipped over & attached one at a time.




2

20 ATTACH 2x LEGS TO LADDER






Using two people assemble 2x legs and ladder bar assembly from step 4.





21 FLIP ASSEMBLY OVER




CRITICAL: ENSURE YOUR FRAME IS 100% SQUARE AND LEVEL (AS PER PAGE 6)
BEFORE MOVING ONTO THE REST OF THE ASSEMBLY


22 SECURE TO GROUND








25 LOAD YOUR TWIRLY WHIRLY BARS X2



 Ensure twirly whirly is level and square & swing leg is pegged down.

3. Pull upwards on the twirly whirly bar to make a slight angle. (Half a bubble off center on the level)



REFER TO VIDEO SECTION OF WEBSITE HTTP://WWW.FUNKYMONKEYBARS.COM/PAGES/VIDEOS

26 ATTACH STICKERS TO FRAME



2x 1 Logo Sticker



1x

Warning Label Sticker



1x

Manufacture Sticker




2x
Australia Made Sticker



4x

S Height Marker Sticker



27

FINAL CHECKS








- Ensure frame is square and level.
 Firmly tighten all grub screws and bolts.
 All base plates are pegged down.

NOTES

28 MAINTENANCE.






At the beginning of each heavy play session (especially a party) and twice a month during play season ensure;

- 1. Tighten all hardware grub screws, nuts and bolts.
- 2. Pegs are in place and fully secure.
- 3. Lubricate all metallic moving parts (trolley and swing hooks.)
- 4. Ensure your frame is level and square.

FAILURE TO DO SO COULD RESULT IN SERIOUS INJURY OR DEATH.

FOR MORE INFORMATION AND ASSEMBLY TIPS PLEASE REFER TO OUR WEBSITE VIDEO INSTRUCTION SECTION AT HTTP://WWW.FUNKYMONKEYBARS.COM/PAGES/VIDEOS

29 HAVE FUN





ABN 72 164 496 520





1300 912 198 info@funkymonkeybars.com www. funkymonkeybars. com

9 Cutting Way, **Yangebup** WA 6164





