


# TERRA

# minipicnic

Woodendot



### Wash & Use

Hand wash with cold water.  
For stains on the corch side, use a damp cloth.  
Not recommended for exterior use since the sun can discolor the fabric.



### Recommendations & Notes

If you want to place a plant pot inside, we recommend using a bottom plate to prevent the fabric to be in direct contact with water.

Pattern may vary slightly since this is a hand painted product.