


QUICK-START GUIDE

A. Assemble the target stand poles, connectors and screen as seen below:



1. Open target screen
2. Connect poles & slide into sleeves
3. Connect corner joints to the poles in the target screen
4. Assemble the target base
5. Connect the target screen to the target base

B. Load the Firing Balls into the Blaster Tube



C. Pull the back handle, then aim and pump forward to fire. The player with the most points wins!



CONTENTS





To ensure that play is both safe and fun, please review these operating instructions with your children:

Failure to follow all safety instructions may result in injury or property damage none of which USA Toyz will be held liable for as proper warnings are outlined in the manual.

- Upon use of this product the end user assumes all responsibility and USA Toyz cannot be held liable for any personal injury and/or property damage.
- This item contains fast moving parts, motors and/or other wiring. When using it, basic precautions should always be followed including but not limited to the following:
 - Keep your eye on the product at all times
 - Tie back hair or wear a hat to avoid entanglement or injury
 - Keep hands, hair and loose clothing away from moving parts when the power switch is turned ON.
 - Please ensure the product is turned off when not in use.

WARNING 	CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE SELLER WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.
----------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------