

ASTROSHOT


• GEMINI EXTREME •



Please include your order number when you contact us at support@usatoyz.com for fast, friendly service.

QUICK-START GUIDE

A. Assemble the target stand poles, connectors and screen as shown below:



1. Open target screen
2. Connect poles & slide into sleeves
3. Connect corner joints to the poles in the target screen
4. Assemble the target base
5. Connect the target screen to the target base


B. Load the fire balls into the Blaster Tube:



C. Pull the back handle, then aim and pump forward to fire. The player with the most points wins!



Target moves left to right.



- Do not mix different types of batteries or old and new batteries.
- Be sure to insert batteries with correct polarity.
- To open battery cover use screwdriver.
- Remove dead batteries from toy.
- The toy requires 4 AA batteries. (Not included)

