



WARNING: \wedge



This product should be assembled by adults. Contains small parts that could be a choking hazard. Not meant for children under 3 years of age.

The contents may vary from the illustration on package

support@usatoyz.com











USA Toyz

GRAVITY GLOBE INSTRUCTION $=M\Delta NU\Delta L$










BOX CONTENTS: LIST

Please refer to the picture below



PICTURE-1



PICTURE-2



INSTRUCTIONS

- 1. Place the base on a level surface, otherwise, it will not float properly.
- 2. Connect the adapter, according to Picture 1. The base light will be on.
- 3. As shown in picture 2, keep the globe's north pole upwards. Place the auxiliary tool between the globe and outer frame. Take your hand off the globe gently, then pull the auxiliary tool gently, the globe will float by itself. If the globe fails to float, try again, pulling the auxiliary tool away slowly.
- **4.** You can make the globe rotate by turning the top half of the globe very gently. The globe rotation direction depends on your starting turning direction.

CAUTION

- 1. Keep other electronic products at least 10cm away from this globe to avoid possible magnetic effects on your electronic devices.
- 2. Dropping the globe on a hard surface may cause damage.

COMPATIBLE WITH:





