

ASTROSHOT

• GYRO •



USA Toyz

Please include your order number
when you contact us at
support@usatoyz.com for fast,
friendly service.

Instruction Manual

Contents:

AstroShot Gyro training kit includes 2 blasters, 24 foam darts and 1 gyro training module. Have a blast!

Assembly:




Insert target holders into base.



Clip rotation obstacles together.




Insert rotation obstacles into base.



Attach dart clip to blaster.



Insert three AA batteries into base.



POWER SWITCH



*Switch on to activate
AstroShot Gyro.*

MUSIC SWITCH



*Play the Space Battle Soundtrack or
switch to Silent Mode. Your move.*



To ensure that play is both safe and fun, please review these operating instructions with your children:

Failure to follow all safety instructions may result in injury or property damage none of which USA Toyz will be held liable for as proper warnings are outlined in the manual.

- **Upon use of this product the end user assumes all responsibility and USA Toyz cannot be held liable for any personal injury and/or property damage.**
- **This item contains fast moving parts, motors and/or other wiring. When using it, basic precautions should always be followed including but not limited to the following:**
- **Keep your eye on the product at all times**
- **Tie back hair or wear a hat to avoid entanglement or injury**
- **Keep hands, hair and loose clothing away from moving parts when the power switch is turned ON.**
- **Please ensure the product is turned off when not in use.**

WARNING 	CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE SELLER WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.
--	--