


Assembly Instructions Ninja Line



😊 Keep this manual for future reference.

EN

DE

FR

ES

IT

EN 01-05

DE 06-11

FR 12-17














ES 18-23

IT 24-29

SAFETY INSTRUCTIONS:

- This product is not intended for public use. ONLY intended for domestic use.
- Not suitable for children below 5 years of age.
- Do not exceed maximum weight 250 LBS.
- Since children have different development patterns, we suggest that adult supervision be required.
- Inspect the strap before each use. Do not use when there is any abrasions, cuts, tears, burns, sew pattern damaged or alterations. If the strap is showing signs of wear, do not use, replace as necessary.


Parts List:

Quantity		
1		1.5in*50ft Slackline
1		Smaller Ratchet for Slackline
1		2in*50ft Ninjaline
1		Bigger Ratchet for Ninjaline
1		Rope ladder
3		Monkey Bar
2		Gym rings
2		Rope knots
9		Triangle clip
9		Carabiners
4		Tree protector cushion
1		Carrying bag
1		Slider pulley Triangle carabiner


Trees Distance before Install

- 50ft line ≠ 50ft trees distance


max.distance - 42ft
tree diameter 7-12in



max.distance - 37ft
tree diameter 15-19in





min.distance - 20ft
tree diameter 7-25in




Assembly Instructions


1. Attach the strap to triangle clip, then move the triangle clip to the other end of the strap where there is a black mark.
Tips1. The distance of triangle clips can be adjusted depends on different environments and users.
Tips2. For safety reasons, we designed the triangle clip to be immovable, if you need to adjust its position, please pull the strap up from the buckle, as shown below, and then move it.)




2. Use the same method to install the other 8 triangle clips. It is recommended that the distance between each triangle clip is 16in.




3. Wrap the cushion around the tree, fasten it. Then set the Ninjaline height to around 12" above the users highest reach.




4. Thread the end of the ninja line(2in *50ft) through the slotted spool from bottom and straighten the line.




5. Pull the ratchet handle up and down until the line is tight, then close and lock the ratchet handle.



6. Ratchet teeth can damage the line. Keep the line and ratchet straight while cranking and do not over fill the ratchet with the line.




7. Hook the obstacles into the clip hole via carabiner, and secure the threaded lock nuts. (Note: the ladder and two of the monkey bars need to put the two connectors into one carabiner, as shown in the figure.)




Slider Pulley Installation


- ① Attach the slider pulley to the ninjaline.
- ② Hook the monkey bar into the slider pulley holes with a carabiner.



8. It is recommended to install the rope ladder on the left or right, as shown in the picture.




9. Wrap the cushion around the tree, fasten it. then set the Slackline (narrower one). You can set and adjust the height of the nether slackerline according to your kids height.
(Tips: Smaller Ratchet for 1.5 in *50ft Slackline)



Release The Line

1. Unlock the ratchet by pulling out the release lever firmly.



2. While holding the release lever in horizontal line, pull the ratchet all the way open until it is released, then pull the line out from the straightened end .

