

 **brio**

SilkStone.®

Electric Pedicure File



Using the SilkStone

Insert the included AA batteries as shown on the back of the device. The battery compartment opens with a quarter turn counter-clockwise. Replace the batteries when the unit operation becomes slower or weaker than normal.

The Brio SilkStone should only be used on clean dry feet. Due to the rapid removal of dry skin, the SilkStone is best used in an area that is easy to clean, such as over a bathtub. Turn the power switch to the on position and move the roller slowly over the bottoms of your feet and heels. It is important to keep the roller moving and not to stop in one place for too long. Areas of thicker skin may require more time. Limit roller time to 3-4 seconds in the same area per session. Use light and consistent pressure. If too much pressure is applied the SilkStone will stop spinning. Stop if the skin becomes sore or inflamed. Rinse and dry feet after use. Use the SilkStone as often as necessary to maintain perfectly smooth feet. For best results, use moisturizer or foot lotion after the SilkStone treatment. Removing the hard outer skin makes your lotion treatment more effective.

Replacing the SilkStone Roller

The SilkStone abrasive wheel will need to be replaced periodically depending on use. With weekly use, the roller should last approximately a month. To replace the roller, pull the roller release switch on the right side of the device and tilt the device forward until the roller falls out. To replace the roller, place the hex end of the roller in first then secure with the roller lock button. The roller lock button will click when the roller is properly installed. Switch the unit on and check for proper alignment and function before use.



Warnings

- For use on thick or callused skin only.
- Do not use on wet skin.
- Stop immediately if irritation or discomfort occurs.
- Do not use on broken, sore or irritated skin.
- Keep out of the reach of children.
- This product should not be used on children.
- Keep long hair or anything that may become tangled in the roller during use.
- Household use only.
- Each roller is recommended for one person only and should not be shared with others.
- Do not use on warts, moles, blemishes, sores or wounds.
- This product is not suitable for diabetics or people with poor circulation.

Cleaning

Clean your Brio SilkStone after each use to ensure best performance. The device is water resistant so it can be rinsed under water. Turn the unit on and hold the head and top of the unit under the running water. Use the included cleaning brush to remove any remaining debris. Once the unit is clean, remove the roller and dry all parts with a clean dry cloth.

Warranty & Support

The Brio SilkStone is guaranteed to function properly for one year from the date of purchase. Defects due to faulty materials and workmanship will be repaired or replaced at Brio's expense with a qualified receipt.

To contact Brio customer service please call (248) 268-6530
For more information on the warranty service process please visit www.brio4life.com



Be a **well** being.

Made in China