Features

- Premium CREE XM-L2 U2 LED
- Maximum output of 500 lumens - Maximum runtime of up to 4 hours on high mode
- Water, dust and impact resistant.

- Multiple output modes are conveniently accessed via button switch

- Constructed from aerospace-grade aluminum alloy

Included Items

- 2 x GOVOLT® 18650 Li-ion Rechargeable Batteries
- 1 x GOVOLT® Dual Charger
- 1 x Wrist Lanyard
- User Manual, Warranty Card

Optional Accessories

- GOVOLT® 18650 Batteries
- GOVOLT® Remote Pressure Switch

Dimensions

Head Diameter: 1.59" / 40.5mm Tail Diameter: 1.05 " / 26.5mm Length 7.90" / 200.6mm

Weight: 6.1oz / 173 grams (without batteries)

Maintenance

Every 6 months, threads should be wiped with a clean cloth followed by a thin coating of silicon-based lubricant.

Warranty Service

All GOVOLT® products are warranted for quality, DOA / defective products can be exchanged for replacement through a local distributor/dealer within the 14 days of purchase. After 14 days, all defective / malfunctioning GOVOLT® products will be repaired free of charge for a period of 18 months from the date of purchase. After 18 months, a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts.

The warranty is nullified in all of the following situations:

- 1. The product(s) is/are broken down, reconstructed and/or modified by unauthorized parties.
- 2. The product(s) is/are damaged through improper use.
- 3. The product(s) is/are damaged by leakage of batteries.

For full terms visit the warranty section at www.govolt.com

For the latest information on GOVOLT® products and services, please visit govolt.com, contact your national GOVOLT® distributor, or send an email to contact@govolt.com.

OPERATING INSTRUCTIONS



BATTERY INSTALLATION (see above diagram)

1. Unscrew the end cap in a counter-clockwise direction. 2. Insert two 18650 Li-lon batteries with the positive poles pointing inward (towards the head)

NOTE: Ensure batteries are inserted with the positive (+) end pointing towards the correct direction. The A4 will not operate with incorrectly inserted batteries

TO CHARGE LI-ION BATTERIES

- 1. Remove batteries from flashlight
- 2. Insert 18650 Li-lon batteries into GOVOLT® Dual Charger with the positive poles pointing downward (towards the Top)
- 3. Wait until indicator light turns from red to green

SWITCHING ON/OFF

TO SWITCH ON: Press the green button on the end cap until a "Click " is heard. TO SWITCH OFF: Press the green button on the end cap a second time until a "Click " is heard.


MODE SWITCHING

The A4 has 3 modes: High, Low, and Strobe.

These 3 modes can be changed by lightly pressing the green button on the End Cap.

ZOOM FUNCTION

To focus or widen the beam, simply pull or push the Head towards or away from the main body of the flashlight.



PERFORMANCE SPECIFICATIONS

FL1 STANDARD	HIGH	MEDIUM	STROBE
314	500 LUMENS	180 LUMENS	250 LUMENS
2X 18650	4h00min	12h00 min	8h00min
M	300 m (Beam Distance)		
	15000 cd (Peak Beam Intensity)		
1.5 m	1.5 m (Impact Resistant)		
	IPX-4 (water Resistant)		



Address: 2445 Hilton Drive, Suite 126 Gainesville, Georgia 30501





USER MANUAL

