# Features

Premium CREE XP-G Q5 LED - Maximum output of 250 lumens - Maximum runtime of up to 4.5 hours on high mode - Water/dust proof and impact resistant. - Multiple output modes are conveniently accessed via button switch - Modes provide customized brightness levels plus strobe - Constructed from aerospace-grade aluminum alloy

# Included Items

3 x AAA Battery User Manual, Warranty Card

# **Optional Accessories**

- GOVOLT<sup>®</sup> Tactical Filter Kit - GOVOLT® Weapon Mount - 30mm

# Dimensions

Head Diameter: 1.5" / 38mm Tail Diameter: 1.18" / 30mm Length: 4.72 inches / 120mm Weight: 4.09 oz / 116g (without battery)

# **OPERATING INSTRUCTIONS**

#### BATTERY INSTALLATION (see above diagram)

1. Unscrew the end cap in a counter-clockwise direction.

2. Remove battery harness

.5m

Govolt

TEL: 888-778-2823

E-mail: info@govolt.com

- 3. Insert three AAA alkaline battery into harness
- 4. Insert battery harness into flashlight.
- 5. Screw back the end cap in a clockwise direction

HIGH

250

LUMENS

NOTE: Ensure batteries are inserted with the positive (+) end pointing towards the correct direction. The G250 will not operate with incorrectly inserted batteries

# Maintenance

Every 6 months, threads should be wiped with a clean cloth followed by a thin coating of silicon-based lubricant.

# Warranty Service

All GOVOLT<sup>®</sup> products are warranted for quality, DOA / defective products can be exchanged for replacement through a local distributor/dealer within the 14 days of purchase. After 14 days, all defective / malfunctioning GOVOLT® products will be repaired free of charge for a period of 18 months from the date of purchase. After 18 months, a limited warranty applies, covering the cost of labor and maintenance, but not the cost of accessories or replacement parts.

#### The warranty is nullified in all of the following situations:

1. The product(s) is/are broken down, reconstructed and/or modified by unauthorized parties. 2. The product(s) is/are damaged through improper use. 3. The product(s) is/are damaged by leakage of batteries.

For full terms visit the warranty section at www.govolt.com


For the latest information on GOVOLT® products and services, please visit govolt.com, contact your national GOVOLT® distributor, or send an email to service@govolt.com.


### SWITCHING ON/OFF

TO SWITCH ON: Press the green button on the end cap until a "Click " is heard. TO SWITCH OFF: Press the green button on the end cap a second time until a "Click " is heard.

#### MODE SWITCHING

The G250 has 3 modes: High, Low, and Strobe. These 3 modes can be changed by lightly pressing the green button on the End Cap.







# **USER MANUAL**

