

There's a screw (C) on the bottom of the sole rod (B) that needs to be removed. That screw (C) goes underneath the base (A) and through the hole. The sole rod (B) then goes on top of the base (A) and is threaded back onto the screw (C).

You will find the screw (C) underneath the sole rod (B).

