



Model 200 Wurlitzer RCA Cable Replacement:

1. Remove screw securing coax cable shield and ground jumper wire to harp.



2. Clip coax conductor wire away from terminal lug. Do NOT cut jumper wire.



3. Add the new cable's conductor terminal lug to the harp at the same location as the existing jumper wire lug.



4. Screw down the new cable's shield terminal lug along with the ground jumper lug removed earlier.

