



WURLITZER 200 SERIES SPEAKER SHUT OFF SWITCH

WIRING DIAGRAM

Insert in place of wires going from Amplifier PCB to Headphone Jack.

