24" Bar Handle Dishwasher

300 Series WATER SOFTENER – Stainless Steel SHXM63WS5N





SHXM63WS5N Stainless Steel

The 3rd rack provides the perfect space for silverware and large utensils while its V shape leaves room below for taller items.

Features & Benefits

44 dBA: dishwasher runs quietly so your kitchen conversations aren't interrupted.

With PrecisionWash™, intelligent sensors and precision spray arms target every item of every load, so dishes come out sparkling clean every time.

The AquaStop® leak protection system contains leaks through a precisely engineered system. If a leak occurs, the system contains it by shutting down operation and pumping out water. So you have the ultimate peace of mind whether you are away or at home.

General Properties	
Number of wash cycles	5
Number of options	4
dBA	44
Third rack	Standard 3rd Rack
Rack adjustability	Rackmatic®
Tub material	Stainless Steel
Control type	Touch Control
Concealed water heating element	Yes
Leak protection system	24/7 AquaStop®
Water softener	Yes
Five-level wash	Yes
ChildLock	No
Special features	InfoLight®, Water Softener
Efficiency	
Water usage per cycle	3.5
Energy efficiency class	Tier 1
ENERGY STAR® qualified	Yes
Total annual energy consumption (kWh)	269
Total annual water consumption (g)	623.5
Capacity	
Number of place settings	16



Technical Details		
Watts (W)	1440 W	
Current (A)	12 Amps	
Volts (V)	120 V	
Frequency (Hz)	60 Hz	
Power cord length - Install length from corner of unit	67"	
	45"	
Minimum water pressure (lb/sin)	14	
Length outlet hose (in)	79"	
Dimensions & Weight		
Overall appliance dimensions (HxWxD) (in)	33 7/8" x 23 9/16" x 23 3/4"	
Required cutout size (HxWxD) (in)	33 7/8" x 23 5/8" x 24"	
Adjustable feet	Yes	
Net weight (lbs)	95 lbs	
Accessories-Optional		
Junction Box	SMZPCJB1UC	
Bosch Dishwasher Water Supply Hose	SMZSH002UC	
Drain Hose Extension Kit	SGZ1010UC	
Dishwasher Accessory Kit	SMZ5000	
Anti-Tarnish Silverware Cassette	SMZ5002UC	
Dishwasher Softener Salt (4.4 lbs)	SGZ9091UC	
Edge Protector	SMZEP001UC	





Accessories: To purchase Bosch accessories, cleaners & parts please visit www.bosch-home.com/us/store or call 1-800-944-2904 (Mon to Fri 5 am to 6 pm PST, Sat 6 am to 3 pm PST).

Notes: All height, width and depth dimensions are shown in inches. BSH reserves the absolute and unrestricted right to change product materials and specifications, at any time, without notice. Consult the product's installation instructions for final dimensional data and other details prior to making cutout.

Warranties: Please see Use & Care manual or Bosch website for statement of limited warranty.