BioLite BaseLantern | BaseLantern XL

IMPORTANT: Read all instructions and warnings before use.

WARNING: BaseLantern contains batteries. Keep away from heat. Store in cool dry area when not in use.


Care & Maintenance: If BaseLantern gets dirty, wipe down with damp towel. The BaseLantern is weather resistant, but not waterproof: do not leave out in rain for prolonged period of time and do not submerge in water.


Product Specifications: Water Resistant. Dimensions: 5.1 x 5.0 x 1.7 in Weight: 1.29 lbs / 1.44 lbs (XL) Inputs: Micro USB charge in Outputs: USB charge out x2, SiteLight port x2 Burn Time: 54 LO, 5 HI / 78 LO, 7.5 HI (XL) Lumens: 500 Lm Battery: 7800 / 12000 (XL) mAh lithium-ion

In The Box: BaseLantern / BaseLantern XL, micro USB cord, quick start instructions

Prior to First Use: DISABLE DEMO MODE

To disable Demo Mode, hold the power button for 10 seconds until the lantern blinks twice. Alternatively, you may also disable Demo Mode by plugging the BaseLantern into any USB power source.





Components & Controls

- 1. Power Button
- 2. Lantern Panel
- 3. 7800/12000 mAh Rechargeable Battery
- 4. Folding Legs
- 5. Micro USB Cord
- 6. Micro USB Charge In 7. USB Charge Out Ports x2
- 8. SiteLight Control Button
- **9.** SiteLight Ports x2



- Prior to first use, charge up your BaseLantern via micro USB. The LED battery life indicator will blink left-to-right to show BaseLantern is charging and the 4 LEDs will turn solid when the battery is full (approx. 5 hours / 8 hours XL).
- BaseLantern features stainless steel legs that raise your lantern and create a wider perimeter of light (1.1).
 You can also utilize the legs for angled task-lighting (1.2) or hanging the lantern like a lightbulb (1.3).







1.1

1.2

1.3



BaseLantern has 4 lighting modes that are accessible through manual operation. To engage additional lighting functionality, please download the BaseLantern Mobile App (See Section 5) and follow setup instructions.


BaseLantern Manual Settings

To change lighting modes, press power button in quick succession (within 2 seconds) until you have reached desired setting.

USAGE TIPS:

- When turning on, BaseLantern's memory returns to its last used lighting function. Simply press power button in quick succession to reach desired setting.
- 2. LOCK MODE: To avoid accidental activation of BaseLantern in transit, hold the power button for 3 seconds while it is OFF. When you want to unlock it, hold again for 3 seconds. It will flash once to indicate it is out of Lock Mode.






3 BASELANTERN + SITELIGHTS

Note: BioLite SiteLights are sold separately from BaseLantern

To expand your outdoor lighting system with overhead lights, connect daisy-chainable BioLite SiteLights to your BaseLantern. Featuring 2 SiteLite ports, the BaseLantern allows you set up string lighting in two directions at once:

- Uncouple SiteLights and extend SiteLight cord to desired length. (3.1)
- 2. Plug SiteLight into BaseLantern SiteLight port. (3.2)
- Daisy-chain desired network of SiteLights together by plugging subsequent SiteLight jacks into preceding SiteLight port. (3.3)
- To turn on and dim SiteLights manually, press SiteLight button located next to SiteLight ports on BaseLantern.
 (3.4) You may control each SiteLight individually via their manual buttons located on top of each light. (3.5)
- To turn on and dim SiteLights remotely, please refer to the BaseLantern mobile app.





Charge Out


BaseLantern's internal li-ion battery may be used for both lighting and external charging to other devices via USB.

- 1. To charge devices, plug charging cord into USB charge-out port located on side of BaseLantern. (4.1)
- If BaseLantern is in OFF setting, press power button once to activate charging. (4.2) You may then turn light panels off to conserve battery while keeping devices charging.
- 3. BaseLantern features [2] USB charge-out ports allowing you to charge two devices at once. Note: When charging two devices, one port will charge at 2.1A while the second will charge at 1A.

Charge In

There are 4 LED lights on the side of your BaseLantern to represent the power reserves of the internal battery. When your battery is below 10%, the first LED on the left will begin flashing -your BaseLantern has entered **Low Power Mode** and will stop offering charge-out to external devices.

- Plug the included micro-USB cord into BaseLantern input port. (4.3)
- 2. Connect to power source such as wall outlet or car charger. (4.4)
- LED battery indicator lights will flash sequentially from left to right to indicate battery is charging. (4.5)
- 4. When battery is fully charged, all 4 LEDs will be lit.



5 BASELANTERN MOBILE APP

The BaseLantern features a free mobile app for iOS and Android. This app enables you to activate sleep timers, proximity activation, color settings, battery life feedback, remote dimming and several other functions all from your smartphone.

Download at: BioliteEnergy.com/baselantern-app


Or visit the Apple or GooglePlay app store and search BaseLantern.





4.2





Automatic On/Off When In Range

Real Time Power Usage Stats

YAX: Lantern Effects

👺 🛮 Turn On, Off & Dim

Alarm & Timers

TROUBLESHOOTING

Problem	Solution
BaseLantern cycles through lighting modes then shuts off.	BaseLantern is in DEMO MODE. To deactivate, hold power button down on BaseLantern for 10 seconds until BaseLantern blinks twice.
BaseLantern blinks twice but will not turn on.	BaseLantern is in LOCK MODE. This is designed to prevent your light from accidentally turning on while in transit. To unlock, hold power button down for 3 seconds until BaseLantern blinks twice.
BaseLantern color mode is not on the correct color and I want to control it manually.	Press and hold to cycle through colors and reach desired color.
BaseLantern not responding to Mobile App commands.	Check your device settings to ensure Bluetooth is on and that BaseLantern has been paired with your phone. Check top left corner of mobile app to verify that system is connected.
SiteLights are not working.	Ensure that all SiteLights are firmly plugged into ports (often requires an extra push) and individual SiteLites are all in manual ON position in order to be controlled from mobile app.

For videos, FAQs, and more please visit BioLiteEnergy.com/Instructions

WARRANTY

BioLite has a 1 year limited warranty. Should this product not function properly under normal use within 1 year of purchase, contact BioLite or your local distributor for return process information. BioLite alone will determine if the problem is due to a manufacturing flaw. If so, BioLite will repair or replace the unit at its discretion and send it to you, free of charge. This warranty does not cover any damage or malfunction arising from misuse, improper maintenance, negligence, normal wear and tear, or accident. Never alter the BaseLantern in any way or use with any part or accessory not expressly approved by BioLite. This warranty applies only to the original purchaser and proof of purchase is required. All implied warranties required under law are limited to one year. BioLite shall not be liable for any consequential or incidental damages whatsoever. BioLite shall not be held liable if the product or defect herein causes damage or failure of other equipment. This warranty gives you specific legal rights. You may also have other rights that vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation or exclusion of implied warranties, so the above exclusions or limitations may not apply to you.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

EU Compliance Statement - BioLite Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive. A copy of the EU Declaration of Conformity is available online at bioliteenergy.com/euro-compliance. BioLite's EU representative is DSV Solutions Nederland BV, Tradeboulevard 4, Haven 528, 4761 RL Moerdijk, P.O. Box 6086, 4780 LX Moerdijk, The Netherlands.

CALIFORNIA PROPOSITION 65 WARNING: This product contains a chemical known to the State of California to cause cancer and birth defects or other reproductive harm.

FCC ID: X8WBT600E







UN38.3