



60cm built under dishwasher with ComfortLift, MaxiFlex cutlery drawer, AirDry technology, beam on floor cycle indicator and 14 place settings.





# **Product Details**

#### FEATURES

ComfortLift ComfortLift makes it easy to load and unload. MaxiFlex MaxiFlex drawer space can be adapted to the load. SatelliteClean SatelliteClean reaches all items with water jets. ExtraHygiene ExtraHygiene removes 99.99% bacteria & viruses\*.

Beam on Floor Beam-on-Floor shows you when its time to unload. AirDry Allows natural airflow in towards the end of the cycle ensuring dry dishes Eco program Eco program is water and energy efficient.

## BENEFITS

#### RAISING THE STANDARD

ComfortLift is the first of its kind, making it easier than ever to load and unload your dishes. The unique hinge mechanism allows you to gently lift the lower rack, meaning you no longer need to bend down low to load and unload heavy plates, platters, pots, and pans.

#### MAKE ROOM FOR MORE

The MaxiFlex drawer accommodates everything from spoons to spatulas. From multiple cutlery sets to over-sized utensils, the flexible dividers mean you can customise the drawer according to the load. Flatware is kept separate from larger items and the added depth increases the capacity for each cycle.

#### THE GLASS-CARE SPECIALIST

SoftGrips and SoftSpikes gently support your delicate glasses, safeguarding them from damage, while the dedicated glassware program means you no longer have to hand wash. SoftGrips gently secure each individual glass stem, while the rubber SoftSpikes cushion glassware from vibration during the wash cycle so they do not move around.

#### MAX COVERAGE. MAX CLEAN

SatelliteClean shoots multiple jets of water into every corner of the dishwasher to ensure every item is thoroughly cleaned. The double rotation movement continuously changes the angle of the water jets to ensure maximum coverage, delivering outstanding cleaning results.



#### CLEAN WITH EXTRA HYGIENE

The ExtraHygiene function gives you maximum cleaning performance with hygienic care. With the ExtraHygiene function, the final rinse phase heats up to above 60C and keeps the temperature high for minimum 10 minutes to sanitize your dishes, removing more than 99.99% of bacteria and viruses.\*\*ExtraHygiene removes more than 99.99% of bacteria and viruses\* with water heated above 60C.\*Tested for Micrococcus leteus and MS2 bacteriophage in external test performance by Swissatest Testmaterialien AG in 2021 (Test report No. 20212029)

#### STATUS CHECK FROM A DISTANCE

Beam-on-Floor projects the status of your wash program so that you can easily see when its time to unload. A red spot on the floor means that the program is still running, while a green spot means that it is completed.

#### UP TO 3X BETTER DRYING\*

AirDry technology finishes each cycle with a breath of fresh air, performing three-times better than closed-door systems. The door automatically opens 10 cms towards the end of the drying phase, without you lifting a finger. This allows air to circulate inside, leaving plates and cutlery completely dry and spotless at the end of the cycle, whilst also saving energy.\* Compared with our closed system.

#### SWITCH TO ECO

Suitable for cleaning normally soiled tableware, the Eco Program is this dishwashers most efficient program for water and energy consumption.



# **Specifications**

# PRODUCT PROFILE

Domestic warranty details (yrs)	2
Type of Dishwashers	built under
Place settings	14
Drying system	AirDry
Number of spray arms	3
Top shower	Yes

### SPECIFICATION

Water efficiency star rating WELS	5
Water consumption (litres)	11.2
Energy Star Rating	3.5
Energy consumption cold water (kWhr/yr)	273
Noise level dBA	44
Water supply	cold or hot (maximum 60°C)
Basket colour	grey
Service cord length	1600
Inverter system	Yes

### DIMENSIONS

### WASH PROGRAMS

8

Total height (mm)	818
Total width (mm)	596

Number of Programs

\_



## DIMENSIONS

Total depth (mm)	
------------------	--

570

## WASH PROGRAMS

Programs	Quick 30 min,Regular 90 min,AUTO Sense,Machine Care,rinse and hold,Light 60 min,Heavy 160 min,ECO 180 min
Wash option	Delay start (1-24 hours),ExtraHygiene,GlassCare,ExtraPower
Range of temperatures	4

## CONTROL PANEL

Control panel type	Touch Control electronic
Top mounted control panel	Yes
Control panel finish	stainless steel
Display indicators	delay start,Beam On Floor Two Coloured,rinse aid,service code,program selected,ExtraHygiene,ExtraPower

# FEATURES

Other Features	beam on floor indicator,Auto Off,delay start
Water safety system	aqua control
Dispenser	detergent,rinse aid
Number of spray levels	3

# EXTERIOR

Door finish	dark stainless steel
Side colour	grey

### **UPPER BASKET**

glass,SoftGrip,Foldable glass rack,easy lift adjustable upper basket	Upper basket features	, , , , , , , , , , , , , , , , , , , ,
--	-----------------------	---

# Electrolux

# ESF97400RKX

# EXTERIOR

Plinth colour (kickboard)	no plinth supplied
Removable worktop	No

# UPPER BASKET

HOSES

Foldable cup shelves	4
Foldable Racks	2

## LOWER BASKET

Lower Basket Features	ComfortLift
Foldable Racks	4
Foldable cup shelves	0

Inlet hose length	1600
extension hose	spare part

# SHIPPING

Shipping Volume (m3)	0.376
Shipping Weight (Kg)	47.7
Pack Dimensions Height (mm)	870
Pack Dimension Width (mm)	635
Pack Dimension Depth (mm)	680

# STUFFING QUANTITIES

40ft HC


150





# Dimensions

Model: ESF97400RKX



© 2022 Electrolux S.E.A PTE. LTD. E\_DIm\_ESF97400RKX\_Apr22



# **Terms and Conditions**

#### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

#### **PRODUCT INFORMATION**

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

#### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067 email: customercare@electrolux.com.au web: www.electrolux.com.au

#### ELECTROLUX HOME PRODUCTS NEW ZEALAND telephone: 09 573 2230 fax: 09 573 2221 email: customercare@electrolux.co.nz web: www.electrolux.co.nz