


MIMOSA AIRCOOL INFANT INSERT

User Manual



<u>₩</u> MIMOSA

Singapore:

Kim Hin Innovation Labs Private Ltd. 601 Sims Drive, Pan-I Complex Singapore 387382 Tel: (65) 6831 5020 care.il@kimhinintl.com

Hong Kong:

Trade Solutions Ltd. Unit D, 13A, Gemstar Tower, No. 23 Man Lok Street, Hung Hom, Kowloon, Hong Kong Tel: (852) 2264 1282

Malaysia:

Global Retail Network Sdn. Bhd. (921399-V)
Wisma Pang Cheng Yean,
Lot 5205C, Jalan Perindustrian Balakong Jaya 1/3,
Taman Perindustrian Balakong Jaya,
43300 Seri Kembangan,
Selangor Darul Ehsan, Malaysia
Tel: (03) 8940 6638
contactus@globalretail.com.my

MMS18005



Compatible with
Mimosa Ergonomic Baby Carrier
Mimosa Airplush 6-Way Hipseat Baby Carrier
Mimosa AirPlush Ergonomic Baby Carrier

1. SAFETY INFORMATION	
2. FEATURES WE LOVE	
3. INSTRUCTIONS FOR INFANT INSERT & CUSHION	
4. INSTRUCTIONS FOR CUSHION ONLY	
5. CARE INSTRUCTIONS	

<u>ii</u>

1. SAFETY INFORMATION

IMPORTANT! Keep instructions for future reference and use. Warning! Read all instructions for the Mimosa AirCool Infant Insert before assembling and using the infant insert.

FALL HAZARD - INFANT CAN FALL THROUGH OR OUT OF CARRIER AND/OR INFANT INSERT!

- Before each use, make sure all fasteners are secure.
- Take special care when leaning or walking.
- DO NOT USE for babies weighing less than 3.2kg (7 lbs).
- ONLY USE for infants between 3.2kg (7 lbs) and 6.8kg (15 lbs).
- Infants must only be carried in the front inward-facing carry position when using Mimosa AirCool Infant Insert and/or Cushion.
- The Mimosa AirCool Infant Insert is not to be used in any other carry positions.
- Be aware that as the baby becomes more active, the baby has a higher risk of falling out of the carrier and/or infant insert.

SUFFOCATION HAZARD!

- Always allow room for head movement. Your baby should be able to move her/his head without pressing her/his face onto your body. Babies under 4 months can suffocate in this product if her/his face is pressed tightly against your body.
- Keep your baby's face free from obstruction at all times.
- Constantly monitor your baby and ensure that the mouth and nose are not blocked. Ensure that her/his airway is clear and breathing is normal at all times.
- There should be a clearance of at least two fingers below your baby's chin. Always check
 that your baby's chin is not resting on her/his chest as this partially closes the airway.
 Her/his breathing may become restricted, which could lead to suffocation.
- Premature infants, infants with respiratory problems, and infants under 4 months are at the greatest risk of suffocation.
- Do not use the insert in a lying or reclined position without the carrier.


OTHER WARNINGS

- For premature, low birthweight babies and toddlers with medical conditions, please seek advice from a health professional before using product.
- Allow yourself time to get used to using the carrier as your sense of balance may be
 affected by the use of a baby carrier. Take special care when bending sideways or
 leaning forward or backwards.
- Never leave your baby unattended in or with the Mimosa AirCool Infant Insert.
- Practice caution as your baby may insert her/his fingers into buckle openings.
- The infant insert should not be used with athletic activities, eg, running, swimming and cycling.

PRECAUTIONS FOR USE AND INSTRUCTIONS FOR AIRCOOL INFANT INSERT:

- The Mimosa AirCool Infant Insert is designed for use with the Mimosa Ergonomic Baby Carrier, Mimosa Airplush 6-Way Hipseat Carrier and the Mimosa Airplush Ergonomic Baby Carrier. For the latest list of compatible carriers, please refer to www.mimosa-online.com.
- Do not use any other infant inserts with Mimosa Carriers as they may be incompatible and may result in injuries.
- The infant insert is designed to help support your baby's head and neck and to help ensure that your baby is sitting correctly in the carrier.
- Use the Mimosa AirCool Infant Insert for babies between 3.2kg (7 lbs) and 6.8kg (15 lbs).

- The infant insert should only be used for the FRONT INWARD-FACING CARRY POSITION, and no other carry positions.
- Infants more than 15 lbs (6.8 kg) but without strong and consistent head and neck control
 must continue using the infant insert when using the carrier.
- Use of the infant insert can be discontinued once baby exceeds 6.8kg (15 lbs) AND has developed a robust and consistent control of the head and neck, usually occurring at the mark of 4 months.
- Practice putting on your carrier before using the infant insert with the carrier.
- As your baby grows, their leg positioning will change. The insert supports the thighs in a squat & spread position, with knees at their belly button and legs resting on the sides of the infant insert inside the carrier. As growth progresses, your baby's knees will become higher than the hips along with the legs resting outside of the infant insert and the carrier.
- Your baby's position should be checked regularly to make sure that your baby is
 properly seated in the infant insert, centered with legs in a squat & spread position, with
 head upright and not slumping downward or to the side.
- Infant's arms, legs and feet need to be observed regularly while in the carrier to ensure that they are not constricted by the carrier.
- Check for ripped seams, straps or fabric, damaged fasteners and other signs of wear and tear before use. Cease usage if the insert is perceived to be damaged.
- The infant insert should not be used unless and until the user has fully read and understands the instructions and safety features as detailed in this manual.
- Discontinue use of the infant insert for a period of time if the baby shows signs of discomfort while being carried. You can resume when your baby can be carried without exhibiting discomfort.
- THIS PRODUCT IS NOT A TOY. Keep the infant insert away from children when it is not in use.
- In very hot climes or during summer, your baby could still become too hot in this product. Please choose the right materials for your baby to wear.
- Our products are handmade and there may be slight variations that do not affect their safety.
- Mimosa uses high quality and safe dyes to ensure that our product will retain its color as
 much as possible, and are free from harmful chemicals. With printed fabric, the colours
 will fade slightly with repeated washes, and this will vary by detergent and locale.
- Contact your retailer or Mimosa customer service for additional assistance if needed.
 For additional information, please visit www.mimosa-online.com.




- \bullet Helps support proper posturing of your baby in the carrier.
- Shaped to provide cushioned support for your baby's head and neck.
- Cool-touch satin cotton and porous fill for your baby's comfort in warm weather locales.
- Designed for lightness and sleekness for long hours of baby carrying.
- Silky smooth fabric reduces frictional redness.
- Two adjustable velcro straps for universal fit for full-term infants.
- \bullet Ultra-soft satin cotton is lush to touch and gently embraces your baby.
- Incorporated harness secures baby in insert.
- Provides an ergonomic M-position seat as your baby grows.
- Cushion elevates the baby and provides better clarity for parents to monitor your baby.
- Removable Cushion can be used separately as a booster seat in the carrier when baby does not yet sit in ergonomic M-position in the carrier.

<u>ṁ</u>

3. INSTRUCTIONS FOR INFANT INSERT & CUSHION

FROM 3.2kg 7lbs TO 6.8kg 15lbs


click	a. Fasten your baby carrier around your waist. Allow the carrier panel to hang loose in front of you.	
	b. i. Spread infant insert flat on the ground and insert the cushion. ii. Ensure cushion is properly fitted in the insert.	
	c. i. Lay your baby facing upwards on the insert, and put your baby's legs through the openings below the harness. ii. Fasten the Velcro on both sides – adjust for a snug fit.	
	d. Lift your baby with insert onto the carrier, so that the base of the insert sits on the front lip of your carrier belt, and is in contact with your tummy.	




4. INSTRUCTIONS FOR CUSHION ONLY



For babies over 5.5kg (12 lbs) with adequate head and neck control, who do not yet sit in m-position in the carrier





e. Adjust the baby carrier by pulling the adjustable straps under your arms forward so that your baby is comfortable and close to your body.



- f. i. Check that your baby's legs are hanging freely off the opening.
 - ii. Check that your baby's airways are clear.

5. CARE INSTRUCTIONS



Hand or machine wash in

cold water



Do not bleach









Do not dry