

POLYMER CLAY BAKING TIPS

IT IS SAFE TO BAKE
POLYMER CLAY IN YOUR HOME
OVEN OR TOASTER OVEN!




ALWAYS USE AN OVEN
THERMOMETER WHEN BAKING
POLYMER CLAY.



ALWAYS PRE-HEAT YOUR OVEN
BEFORE BAKING YOUR CREATION.



TO KEEP THE BACK OF YOUR CLAY
FROM BEING SHINY, BAKE ON A
PIECE OF COPY PAPER OR INDEX
CARD.



BAKING SURFACES INCLUDE -
METAL PANS, GLASS, CERAMIC
TILES, INDEX CARDS & BATTING.



TO PREVENT BROWN SPOTS FROM
OVEN SPIKES, TENT YOUR WORK
WITH ALUMINUM FOIL PANS OR AN
INDEX CARD.



NEW KILNS THAT GO DOWN TO
275°F CAN BE USED TO BAKE
POLYMER CLAY!



YOU CAN BAKE YOUR POLYMER
CLAY MORE THAN ONCE! THIS IS A
COMMON PRACTICE FOR INTRICATE
PIECES. YOU CAN ATTACH RAW
CLAY TO BAKED CLAY AND
BAKE AGAIN!



NEVER MICROWAVE YOUR
POLYMER CLAY.



ALWAYS BAKE POLYMER CLAY AT THE
TEMPERATURE AND TIME
RECOMMENDED ON THE
PACKAGING. IF YOU ARE MIXING
TWO BRANDS OF CLAY USE THE
HIGHER TIME AND TEMP OF THE
TWO.

