




Single Harper Pull Handle








Single Harper Pull Handle






Please Note


The double-sided pad can be used to secure the plate to the door. This is to assist with uneven door surfaces. Once attached to the plate, it cannot be removed. Only use if the plate is not stable without it.

Rubber washers can be used to protect the door frame but will be visable.




Double Harper Pull Handle








Double Harper Pull Handle





Please Note

The double-sided pad can be used to secure the plate to the door. This is to assist with uneven door surfaces. Once attached to the plate, it cannot be removed. Only use if the plate is not stable without it.

Rubber washers can be used to protect the door frame but they will be visable. **Rubber washers must** be used when attaching to glass doors.