

Outdoor Wall Decals

- **Easy Installation Tips**

- RECOMMENDED APPLICATION TEMPERATURE IS 25 – 86 DEGREES F. BE SURE TO CLEAN THE SURFACE WITH A BROOM TO REMOVE ALL LOOSE DEBRIS. IF NECESSARY, WASH THE SURFACE WITH REGULAR SOAP & WATER AND BE SURE THE AREA IS COMPLETELY DRY BEFORE APPLYING YOUR DECAL.
- BEFORE REMOVING THE BACKING PAPER OF YOUR DECALS, POSITION IT IN THE DESIRED AREA (ASK SOMEONE TO HELP FOR LARGER APPLICATIONS), TAKE A STEP BACK, AND ADJUST AS NECESSARY
- TAPE THE WALL DECAL IN PLACE ON 4 SIDES AND MAKE SURE IT IS CENTERED AND SQUARE. A TAPE MEASURE CAN ENSURE ACCURACY!
- REMOVE THE UPPER LEFT OR RIGHT CORNER OF THE DECAL FROM THE BACKING PAPER.
- START TO APPLY THE DECAL BY REMOVING THE BACKING PAPER FROM ONE CORNER OR SIDE, WORKING TOWARD THE OPPOSITE SIDE. TAKE YOUR TIME! OUR WALL DECALS DO NOT TEAR OR WRINKLE AND ARE EASILY REPOSITIONABLE.

- **Cleaning**

- WHEN THE GRAPHIC IS VISIBLY DIRTY, CLEAN WITH A SOFT CLOTH, SOAP AND WATER.

- **Removal**

TO REMOVE THE GRAPHIC, SIMPLY LIFT ONE CORNER AND CONTINUE TO PULL BACK SLOWLY.

For All Other Decal Installations, Please Contact Us for Detailed Information!

*Sportdecals, Inc.
800-435-6110
www.sportdecals.com*