



214737 Instruction

Part	Description	QTY
A	Upright A	1
B	Upright B	1
C	Upright C	1
D	Upright D	1
E	Bottom Connect Tube	2
F	Top Connect Tube	2
G	Curve Connect Tube	1
H	Top Fix Plate	1
I	Bottom Fix Plate	1
J	Wood Backboard with Mirror	1
K	Wood Backboard	1
L	Curtain	1
M	1/4" Screw with washer	4
N	5/16" Screw with washer	20
O	1/2"-13x1" Leveler	4
P	4mm Allen wrench	1
Q	5mm Allen wrench	1




214737 Instruction

Step 1




Step 2




214737 Instruction

Step 3




Step 4



214737 Instruction

Step 5



Step 6

