## 130450 **Installation instruction**

## Parts



Step 1 Install wheels-- tighten the wheel screws to the nuts








Step 2 Connect vertical pole with bottom pole with screws





Step 3 Install the "white board holder" to the top of vertical pole with big nut





Step 4 Screw the telescopic poles and connect them with vertical poles with screws, one in the middle and one on the bottom







Step 5 Put white board on the stand, adjust height to your need and tighten screws

TIPS: extend length of "telescopic pole" to put in the white board



Please note: This product ships with a clear protective film on both sides of the whiteboard's surface. The film can be difficult to detect, but should be carefully removed prior to use.

If you choose not to remove this film, dry erase markers will leave a faint permanent mark on the film. When the thin protective film is removed, dry erase markers will not leave markings on the whiteboard surface.

## All done!



Please note: This product ships with a clear protective film on both sides of the whiteboard's surface. The film can be difficult to detect, but should be carefully removed prior to use.

If you choose not to remove this film, dry erase markers will leave a faint permanent mark on the film. When the thin protective film is removed, dry erase markers will not leave markings on the whiteboard surface.