



4-FOOT SHOWCASE

214204 - MAPLE
214234 - CHERRY
214138 - BLACK
214139 - WHITE




5-FOOT SHOWCASE

214205 - MAPLE
214235 - CHERRY
214140 - BLACK
214141 - WHITE



6-FOOT SHOWCASE

214206 - MAPLE
214236 - CHERRY
214142 - BLACK
214143 - WHITE







NOTE: It is recommended that two persons assemble this unit.




ASSEMBLY INSTRUCTIONS

PARTS LIST


PARTS & QUANTITIES SHOWN ARE FOR ONE COMPLETE SHOWCASE UNIT. GLASS PANELS, FELT STRIP AND PLASTIC GASKET NOT FURNISHED WITH THIS KIT.




(2) For 4-ft. Showcase unit
(3) For 5-ft. & 6-ft. Showcase unit




TOOLS REQUIRED





1



2




3





6mm groove

2mm groove

4





5




Fasten panels together and make sure all cams are locked.

6





Fasten panels together and make sure all cams are locked.

7




FRONT GLASS PANEL
(Not furnished with kit.)

8




**Fasten panels together and
make sure all cams are locked.**

9




10




4-FOOT SHOWCASE

214204 - MAPLE
214234 - CHERRY
214138 - BLACK
214139 - WHITE




5-FOOT SHOWCASE

214205 - MAPLE
214235 - CHERRY
214140 - BLACK
214141 - WHITE



6-FOOT SHOWCASE

214206 - MAPLE
214236 - CHERRY
214142 - BLACK
214143 - WHITE



NOTE: It is recommended that two persons assemble this unit.

ASSEMBLY INSTRUCTIONS