

Salvi Harps: Prima 38				
String # counting from top	String # on package	Note	Octave	String Type
1	3	C	1st Octave	Lever Nylon
2	4	B	1st Octave	Lever Nylon
3	5	A	1st Octave	Lever Nylon
4	6	G	1st Octave	Lever Nylon
5	7	F	1st Octave	Lever Nylon
6	8	E	2nd Octave	Lever Nylon
7	9	D	2nd Octave	Lever Nylon
8	10	C	2nd Octave	Lever Nylon
9	11	B	2nd Octave	Lever Nylon
10	12	A	2nd Octave	Lever Nylon
11	13	G	2nd Octave	Lever Nylon
12	14	F	2nd Octave	Lever Nylon
13	15	E	3rd Octave	Lever Gut
14	16	D	3rd Octave	Lever Gut
15	17	C	3rd Octave	Lever Gut
16	18	B	3rd Octave	Lever Gut
17	19	A	3rd Octave	Lever Gut
18	20	G	3rd Octave	Lever Gut
19	21	F	3rd Octave	Lever Gut
20	22	E	4th Octave	Lever Gut
21	23	D	4th Octave	Lever Gut
22	24	C	4th Octave (Middle C)	Lever Gut
23	25	B	4th Octave	Lever Gut
24	26	A	4th Octave	Lever Gut
25	27	G	4th Octave	Lever Gut
26	28	F	4th Octave	Lever Gut
27	29	E	5th Octave	Lever Gut
28	30	D	5th Octave	Lever Gut
29	31	C	5th Octave	Lever Wire
30	32	B	5th Octave	Lever Wire
31	33	A	5th Octave	Lever Wire
32	34	G	5th Octave	Lever Wire
33	35	F	5th Octave	Lever Wire
34	36	E	6th Octave	Lever Wire
35	37	D	6th Octave	Lever Wire
36	38	C	6th Octave	Lever Wire
37	39	B	6th Octave	Lever Wire
38	40	A	6th Octave	Lever Wire

This string list is provided as a courtesy  
 by the Sylvia Woods Harp Center  
[www.harpcenter.com](http://www.harpcenter.com)  
 1-800-272-4277 or 818-956-1363  
 String gauges are subject to change without notice