

carlson[®]
PET PRODUCTS

FOLDABLE SECURE CRATE

**Cage sécuritaire au design pliable
Jaula de seguridad plegable**

Models / Modèles / Modelos:

6002, 6003, 6004, 6005, 6006, 6007, 6008



- READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF PRODUCT. KEEP INSTRUCTIONS FOR FUTURE USE.
- LIRE TOUTES LES INSTRUCTIONS AVANT D'ASSEMBLER ET D'UTILISER PRODUIT. CONSERVER CES INSTRUCTIONS POUR UNE UTILISATION ULTÉRIEURE.
- LEA TODAS LAS INSTRUCCIONES ANTES DE MONTAR Y USAR PRODUCTO. GUÁRDENLAS PARA UTILIZARLAS COMO REFERENCIA.



Carlson Pet Products, Inc.
3200 Corporate Center Drive, Suite 105 /
Burnsville, MN 55306, USA / , É.-U. / , EE. UU.




www.carlsonpetproducts.com



952.435.1084

Made in Vietnam / Fabriqué en Vietnam / Hecha en Vietnam

Before Assembly

A

PLEASE CHECK TO MAKE SURE YOU HAVE THE FOLLOWING PARTS:

A Crate (1)

BEFORE USING PRODUCT

Read and follow all instructions carefully to ensure that your crate is properly assembled. Improper assembly could result in the crate becoming unsafe. Please keep these instructions for your reference.

CARE AND MAINTENANCE


Periodically check the pen for signs of damage, wear, or missing components. Do not use if any part is missing, worn or damaged. Do not use abrasive cleaners or bleach. Clean with warm water and a mild detergent. Do not machine wash.

90 DAYS LIMITED WARRANTY

If, during the first 90 days after consumer purchase of the item, under reasonable and non-commercial use and conditions of maintenance, it fails while owned by the original purchaser because of the quality of materials or workmanship of finish and assembly, Carlson Pet Products, Inc. will replace or repair it at Carlson's option. PROOF OF PURCHASE REQUIRED.


Assembling Your Crate

STEP 1




Set the crate on the ground with the tray on the bottom. Unhook the latch from the side of the crate.

STEP 2



Unfold the panels, like turning the page of a book. Then pull upwards from the middle of the crate panels.


STEP 3



Hold the top panel up, reach inside the crate and pull the door panel forward until it snaps into the 7 hooks located around the edges of the crate.

NOTE: A forceful pull will allow the hooks to snap into place.

STEP 4




Repeat Step 3 on the other side of the crate. Attach handle to center top crate panel, as shown illustrated.

NOTE: For cleaning purposes, the bottom tray is removable. Do NOT carry pet in crate with handle.

Operating the Door


STEP 1



To open, lift up the locking handle and slide to the left to release from the crate frame. If your crate has more than one locking handle repeat step for all locking handles to open the door.

NOTE: Crate size extra small and small include one latch on front door.

STEP 2



To close, lift up and slide the locking handle all the way to the left and shut the door. Slide the locking handle to the right and push down to secure the locking handle to the crate frame. If your crate has more than one locking handle repeat step for all locking handles to open the door.

Disassembling your crate

STEP 1

Unhook the 7 hooks located around the edges of the door panel by pushing the panel into the crate.

STEP 2


Repeat Step 1 on the other side of the crate.

STEP 3

Allow the panels to all collapse flat. Fold the panels, like turning the page of a book.

STEP 4

Hook the latch on the side of the crate to lock all the panels together.

A

VEUILLEZ VÉRIFIER QUE VOUS DISPOSEZ DES ARTICLES SUIVANTS :

A Cage pour animaux de compagnie (1)

AVANT D'UTILISER LE PRODUIT

Lire et suivre attentivement les instructions pour assurer un assemblage conforme de la cage. Un assemblage inapproprié pourrait rendre la cage dangereuse. Prière de conserver ces instructions pour consultation.

GARANTIE LIMITÉE DE 90 JOURS


Si, au cours des 90 jours suivant l'achat de cet article, dans des circonstances raisonnables et dans des conditions d'utilisation et d'entretien non commerciales, l'article, qui appartient encore à l'acheteur original, s'avère défectueux en ce qui a trait à la qualité des matériaux ou aux travaux de finition et d'assemblage, Carlson Pet Products, Inc. le remplacera ou le réparera à son choix. PREUVE D'ACHAT REQUISE.

SOIN ET ENTRETIEN

Vérifiez régulièrement que le parc ne présente pas de signe de dommage, d'usure et qu'aucune pièce ne manque. Cessez de l'utiliser si une pièce manque, est usée ou est endommagée. N'utilisez pas de produit nettoyant abrasif, ni d'agent de blanchiment. Nettoyez avec de l'eau tiède et un détergent doux. Ne pas laver à la machine.


Assemblage de la cage

ÉTAPE 1




Placer la cage sur le sol avec le plateau au fond. Déverrouiller le loquet se trouvant sur le côté de la cage.

ÉTAPE 2



Déplier les panneaux, comme lorsque l'on tourne les pages d'un livre. Tirer ensuite vers le haut à partir du centre des panneaux de la cage.


ÉTAPE 3



Tenir le panneau du dessus vers le haut, insérer la main dans la cage et tirer le panneau de la porte vers l'avant jusqu'à ce qu'il s'enclenche dans les 7 crochets qui se trouvent sur le pourtour de la cage.

REMARQUE : Tirer fermement pour permettre aux crochets de s'enclencher en place.

ÉTAPE 4



Répéter l'étape 3 de l'autre côté de la cage. Fixez la poignée au panneau supérieur central de la caisse, comme illustré.

REMARQUE : Le plateau du bas est amovible pour faciliter le nettoyage.