



Technical Data

Nexus Grid Rockers

Brief product description:

The Nexus Grid range is ideal for domestic, commercial and industrial applications, and allows you to build your own module configurations with a variety of combinations and finishes.

Features:

- Replacement rockers available in all finishes
- Plastic – printed, metal – embossed
- Supplied in packs of 10
- Easy to fit on standard Grid switch modules

Product Images




Printed / Embossed Rocker options include:

Air Con, Bell Symbol, Boiler, Cooker Hood, Dish Washer, Fan, Freezer, Fridge, Fridge Freezer, Heater, Hob, Microwave, Oven, Tumble Dryer, Warming Drawer, Washing Machine, Waste Disposal, Water Heater, Wine Cooler

Unprinted Rocker Options include:

White, Black Nickel, Polished Chrome, Brushed Steel, Part M (Graphite), Red, Antique Brass, Matt Black

Line Diagrams





Nexus Grid Rockers

Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
White Moulded										
RRACW	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204910	5050765205665	5050765206419
RRBELLW	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204934	5050765205689	5050765206433
RRBLW	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204866	5050765205610	5050765206365
RRCHW	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204880	5050765205634	5050765206389
RRDWW	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204927	5050765205672	5050765206426
RRFNW	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204804	5050765205559	5050765206303
RRFZW	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204842	5050765205597	5050765206341
RRFDW	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204835	5050765205580	5050765206334
RRFFW	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204859	5050765205603	5050765206358
RRHTW	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204958	5050765205702	5050765206457
RRHBW	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204781	5050765205535	5050765206280
RRMWW	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204873	5050765205627	5050765206372
RROVW	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204798	5050765205542	5050765206297
RRTDW	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204828	5050765205573	5050765206327
RRWDW	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230940	5050765231015	5050765231084
RRWMW	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204811	5050765205566	5050765206310
RRWDISW	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204903	5050765205658	5050765206402
RRWHW	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204897	5050765205641	5050765206396
RRWCW	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765227063	5050765227070	5050765227087
RRUPW	UNPRINTED - WH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204941	5050765205696	5050765206440
Evolve White										
RRACPCDW	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233439	5050765233798	5050765234153
RRBELLPCDW	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233453	5050765233811	5050765234177
RRBLPCDW	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233385	5050765233743	5050765234108
RRCHPCDW	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233408	5050765233767	5050765234122
RRDWPCDW	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233446	5050765233804	5050765234160
RRFNPCDW	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233323	5050765233682	5050765234047
RRFZPCDW	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233361	5050765233729	5050765234085
RRFDPCDW	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233354	5050765233712	5050765234078
RRFFPCDW	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233378	5050765233736	5050765234092
RRHTPCDW	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233460	5050765233828	5050765234184
RRHBPCDW	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233309	5050765233668	5050765234023
RRMWPCDW	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233392	5050765233750	5050765234115
RROVPCDW	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233316	5050765233675	5050765234030
RRTDPCDW	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233347	5050765233705	5050765234061
RRWDPCDW	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237246	5050765237253	5050765237260
RRWMPCDW	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233330	5050765233699	5050765234054
RRWDISPCDW	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233422	5050765233781	5050765234146
RRWHPCDW	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233415	5050765233774	5050765234139
RRWCPCDW	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237215	5050765237222	5050765237239
RRUPPCDW	UNPRINTED - EVWH	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233477	5050765233835	5050765234191
Evolve Black										
RRACPCDB	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233613	5050765233972	5050765234337
RRBELLPCDB	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233637	5050765233996	5050765234351
RRBLPCDB	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233569	5050765233927	5050765234283
RRCHPCDB	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233583	5050765233941	5050765234306
RRDWPCDB	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233620	5050765233989	5050765234344
RRFNPCDB	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233507	5050765233866	5050765234221
RRFZPCDB	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233545	5050765233903	5050765234269
RRFDPCDB	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233538	5050765233897	5050765234252
RRFFPCDB	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233552	5050765233910	5050765234276
RRHTPCDB	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233644	5050765234009	5050765234368
RRHBPCDB	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233484	5050765233842	5050765234207
RRMWPCDB	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233576	5050765233934	5050765234290
RROVPCDB	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233491	5050765233859	5050765234214
RRTDPCDB	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233521	5050765233880	5050765234245
RRWDPCDB	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237185	5050765237192	5050765237208
RRWMPCDB	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233514	5050765233873	5050765234238
RRWDISPCDB	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233606	5050765233965	5050765234320
RRWHPCDB	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233590	5050765233958	5050765234313
RRWCPCDB	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765237154	5050765237161	5050765237178
RRUPPCDB	UNPRINTED - EVBK	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765233651	5050765234016	5050765234375



Nexus Grid Rockers

Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
Polished Chrome										
RRACPC	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205115	5050765205863	5050765206617
RRBLPC	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205061	5050765205818	5050765206563
RRBELLPC	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205139	5050765205887	5050765206631
RRCHPC	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205085	5050765205832	5050765206587
RRDWPC	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205122	5050765205870	5050765206624
RRFNPC	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205009	5050765205757	5050765206501
RRFZPC	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205047	5050765205795	5050765206549
RRFDPC	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205030	5050765205788	5050765206532
RRFFPC	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205054	5050765205801	5050765206556
RRHTPC	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205146	5050765205894	5050765206648
RRHBPC	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204989	5050765205733	5050765206488
RRMWPC	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205078	5050765205825	5050765206570
RROVPC	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204996	5050765205740	5050765206495
RRTDPC	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205023	5050765205771	5050765206525
RRWMPC	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205016	5050765205764	5050765206518
RRWHPC	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205092	5050765205849	5050765206594
RRWDPC	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230964	5050765231039	5050765231107
RRWDISPC	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205108	5050765205856	5050765206600
RRWCPC	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230957	5050765231022	5050765231091
RRUPPC	UNPRINTED - PC	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205153	5050765205900	5050765206655
Brushed Steel										
RRACBS	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205290	5050765206044	5050765206792
RRBELLBS	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205313	5050765206068	5050765206815
RRBLBS	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205245	5050765205993	5050765206747
RRCHBS	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205269	5050765206013	5050765206761
RRDWBS	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205306	5050765206051	5050765206808
RRFNBS	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205184	5050765205931	5050765206686
RRFZBS	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205221	5050765205979	5050765206723
RRFDBS	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205214	5050765205962	5050765206716
RRFFBS	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205238	5050765205986	5050765206730
RRHTBS	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205320	5050765206075	5050765206822
RRHBBS	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205160	5050765205917	5050765206662
RRMWBS	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205252	5050765206006	5050765206754
RROVBS	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205177	5050765205924	5050765206679
RRTDBS	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205207	5050765205955	5050765206709
RRWDBS	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230988	5050765231053	5050765231121
RRWMBS	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205191	5050765205948	5050765206693
RRWHBS	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205276	5050765206020	5050765206778
RRWDISBS	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205283	5050765206037	5050765206785
RRWCBS	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230971	5050765231046	5050765231114
RRUPBS	UNPRINTED - BS	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205337	5050765206082	5050765206839
Black Nickel										
RRACBN	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205474	5050765206228	5050765206976
RRBELLBN	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205498	5050765206242	5050765206990
RRBLBN	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205429	5050765206174	5050765206921
RRCHBN	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205443	5050765206198	5050765206945
RRDWBN	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205481	5050765206235	5050765206983
RRFNBN	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205368	5050765206112	5050765206860
RRFZBN	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205405	5050765206150	5050765206907
RRFDBN	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205399	5050765206143	5050765206891
RRFFBN	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205412	5050765206167	5050765206914
RRHTBN	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205504	5050765206259	5050765207003
RRHBBN	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205344	5050765206099	5050765206846
RRMWBN	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205436	5050765206181	5050765206938
RROVBN	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205351	5050765206105	5050765206853
RRTDBN	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205382	5050765206136	5050765206884
RRWDBN	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765231008	5050765231077	5050765231145
RRWMBN	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205375	5050765206129	5050765206877
RRWDISBN	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205467	5050765206211	5050765206969
RRWHBN	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205450	5050765206204	5050765206952
RRWCBN	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765230995	5050765231060	5050765231138
RRUPBN	UNPRINTED - BN	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205511	5050765206266	5050765207010



Nexus Grid Rockers

Packaging Information

Cat No.	Description	Packaging Type			Pack Quantity			Barcode		
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Individual	Inner Box	Outer Box
Matt Black										
RRACFB	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239226	5050765239424	5050765239622
RRBELLFB	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239233	5050765239431	5050765239639
RRBLFB	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239240	5050765239448	5050765239646
RRCHF	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239257	5050765239455	5050765239653
RRDWFB	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239264	5050765239462	5050765239660
RRFNFB	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239295	5050765239493	5050765239691
RRFZFB	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239301	5050765239509	5050765239707
RRFDFB	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239271	5050765239479	5050765239677
RRFFFB	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239288	5050765239486	5050765239684
RRHTFB	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239325	5050765239523	5050765239721
RRHFB	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239318	5050765239516	5050765239714
RRMWFB	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239332	5050765239530	5050765239738
RROVFB	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239349	5050765239547	5050765239745
RRTDFB	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239356	5050765239554	5050765239752
RRWMFB	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239417	5050765239615	5050765239813
RRWHFB	"WASHING MACHINE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239400	5050765239608	5050765239806
RRWDFB	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239387	5050765239585	5050765239783
RRWDISFB	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239394	5050765239592	5050765239790
RRWCFB	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239370	5050765239578	5050765239776
RRUPFB	UNPRINTED - FB	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765239363	5050765239561	5050765239769
Antique Brass										
RRACAB	"AIR CON"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248235	5050765248426	5050765248617
RRBELLAB	BELL SYMBOL	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248242	5050765248433	5050765248624
RRBLAB	"BOILER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248259	5050765248440	5050765248631
RRCHAB	"COOKER HOOD"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248266	5050765248457	5050765248648
RRDWAB	"DISH WASHER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248273	5050765248464	5050765248655
RRFNAB	"FAN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248303	5050765248495	5050765248686
RRFZAB	"FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248310	5050765248501	5050765248693
RRFDAB	"FRIDGE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248280	5050765248471	5050765248662
RRFFAB	"FRIDGE FREEZER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248297	5050765248488	5050765248679
RRHTAB	"HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248334	5050765248525	5050765248716
RRHAB	"HOB"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248327	5050765248518	5050765248709
RRMWAB	"MICROWAVE"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248341	5050765248532	5050765248723
RROVAB	"OVEN"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248358	5050765248549	5050765248730
RRTDAB	"TUMBLE DRYER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248365	5050765248556	5050765248747
RRWDAB	"WARMING DRAWER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248389	5050765248570	5050765248761
RRWMAB	"WASHING MC"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248419	5050765248600	5050765248792
RRWDISAB	"WASTE DISPOSAL"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248396	5050765248587	5050765248778
RRWHAB	"WATER HEATER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248402	5050765248594	5050765248785
RRWCAB	"WINE COOLER"	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765248372	5050765248563	5050765248754
RRUPAB	UNPRINTED	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765205528	5050765206273	5050765207027
Red										
RRUPRD	UNPRINTED - RED	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204965	5050765205719	5050765206464
Graphite										
RRUPG	UNPRINTED - GR (PART M)	Bag	Colour Box	Carton	10	10 x 10	100 x 10	5050765204972	5050765205726	5050765206471



Nexus Grid Rockers

Weights & Dimensions

Cat No.	Description	Dimensions (H x W x D) cm			Weight (kg)			CBM (m ³)
		Product	Inner Box	Outer Box	Each	Inner Box	Outer Box	Outer Box
RR**W	WHITE MOULDED ROCKERS	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.03	0.33	3.47	0.00952
RR**PCD*	EVOLVE ROCKERS	1 X 8.8 X 6	6.2 x 7.7 x 14.7	16.5 x 16.0 x 32.0	0.03	0.33	3.48	0.00845
RR**FB	MATT BLACK ROCKERS	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.048	0.51	5.27	0.00952
RR**PC	POLISHED CHROME ROCKERS	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.046	0.49	5.07	0.00952
RR**BS	BRUSHED STEEL ROCKERS	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.048	0.51	5.27	0.00952
RR**BN	BLACK NICKEL ROCKERS	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.048	0.51	5.27	0.00952
RRUPRD	UNPRINTED - RED	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.043	0.46	4.77	0.00952
RRUPG	UNPRINTED - GR (PART M)	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.043	0.46	4.77	0.00952
RRUPAB	UNPRINTED - AB	1 X 8.8 X 6	7 X 9.7 X 11.8	13.1 X 20.3 X 35.8	0.043	0.46	4.77	0.00952