



## GF-120T PART LIST

NO.	PART NAME	UNIT QTY	PART CODE
1	Right side plate	1	
2	Adjustable leg(6")	4	70200900019
3	Strengthening sheet of side plate	2	
4	Clamp	2	
5	Rear bottom beam	1	
6	Inlet pipe	1	70201804791
7	Gas safety valve SIT	2	
8A	Gas distributing pipe(Left)	1	70201807028L
8B	Gas distributing pipe(Right)	1	70201807037L
9	Testing nut	2	
10	TEMP. limiter	2	70202200737
11	Thermostat	2	70202200728
12	Thermostat knob	2	70101103628
13	Front bottom beam	1	
14	Supporting plate for door shaft	1	
15	Oil drainage extension pipe	2	70202018273
16	Door housing	1	

17	Front plate	2	
18	Front top beam	1	
19	Assembling bracket of gas distributing pipe	1	
20A	Right Burner	2	70201301046
20B	Left Burner	2	70201300946
21	Oil drain valve	2	70200500746
22	Pilot connecting plate	2	
23	Thermocouple	2	70201700155
24	Pilot Bracket(NG)	2	70201302028
24A	Pilot Bracket(LPG)	2	70201302019
25	Thermal pile	2	70201700237
26	Tank assembly	2	
27	Supporting grid	2	70201106928L
28	Basket	2	70201105746
29	Chimney extension assembly	2	
30	Rear coaming assembly	1	
31	Basket hanger	1	
32	Rear plate	1	
33	Left side plate	1	