




GN1410TN & GN1410BT



12	control panel	CC1400-B26-02-A0	1	cabinet	CN1400BXTA201
13	switch	RL2-GR			CN1400BXTA304
14	temperature controller	XR02CX-5R0C1 XR06CX-5R0C1	2	cassette unit	CC1400BRS CN1400BGFS
15	fan switch	HC-050K4	3	upper left hinge	L700-B63-01-A0
16	lock	WJ13-02	4	upper right hinge	L700-B64-01-A0
17	door	CC700BMTA201 CC700BMTA304	5	heating line	L700-D06-JRS
18	transformer	ZF120A-1200420	6	lower hinge	WJ09-06
19	lamp	BL-TK-A	7	Feet adjustable	WJ12-22
20	Middle beam	L1400ZL201-B0 L1400ZL304-B0	8	ladder	L700-B42-01-C2
			9	shelf	WJ11-01
			10	guide	L700-B43-01-A1
			11	door gasket	SL12-07