



PT---Timer

ST---Proportional Switch

HL---Heating Indicator

EH---Heating Element