

HAMOKI

YSD-6A PART LIST

S/N	Description (English)	Part Code	Unit QTY
1	Door shaft sleeve	70202006319	4
2	Inner door glass	70201001982	1
3	Door frame pressing strip	70200200937L	3.5
4	Outer door glass	70201001973	1
5	Door handle	70200700800	1
6	Door frame assy		1
7	Right grid shelf	70201102391	1
8	Grid	70201102237	1
9	Left grid shelf	70201102228	1
10	Front bracket of heater		1
11	Indicator light	70101300128	4
12	Bottom heater 230V/2kW	70100403891	1
13	Heater supporting plate		1
14	Green switch	70100800573	2
15	Red switch	70100800564	1
16	Thermostat 110°C	70100300073	1
17	Thermostat control knob	70101100946	3
18	Timer 180 minutes	70101200137	1
19	Timer 60 minutes	70101200282	1
20	Thermostat 320°C	70100300819	1
21	Lock shaft	70202007291	1
22	Lock shaft insert	70202007300	1
23	Rubber foot	70200900228	4
24	Screw	70202007282	2
25	Chamber lamp 230V/15W	70101300482	1
26	Chamber lamp base and cover	70101300382	1
27	Motor	70100101319	1
28	Power cord sheath	70100700700	1
29	Power cord		1
30	Terminal box	70100701391	1
31	Relay	70100900791	1
32	Rubber gasket \varnothing 22	70100700673	1
33	Buzzer	70101000028	1
34	Micro switch	70100800619	1
35	Cap of micro switch pushing rod	70202008028	1
36	Micro switch pushing rod	70202007328	1
37	Chamber assy		1
38	Air deflector		1
39	Top heater 230V/2.6kW	70100403873	1
40	Chimney assy		1
41	Chimney fixing sleeve		1
42	Top plate		1
43	Housing assy		1
44	Door spindle	70202006300	4

