

SD800/ZT-07 Transmitter programming

Programming new transmitters

1. Additional transmitters can be coded as follows: Press and hold the “P” and “+” buttons until all lights turn on and LED 7 flashes
2. Press the “+” button once (all LED lights turn off except LED 7)
3. Quickly press and release the required button on your remote twice (all LED lights turn on and LED 7 will begin flashing)
4. Press the “P” button once to save (LED 3 will switch on indicating that the remote has been successfully programmed) Repeat above procedure for all additional handsets.

Note: A maximum of six (6) codes can be learned by the opener. If you attempt to code more than six (6) transmitters the first code will be deleted.