

REDCAT 51

QUICK START GUIDE





REDCAT 51 QUICK START GUIDE

PARTS



Lens Hood/Dew Shield

The [D] Lens Hood on the redcat is convertable for storage. Which it has to be inverted before use. Remove the cat logo lens cap first, unscrew the hood from the body then reinstalling it outward firmly.

Camera adapter

Remove part [E] M48 Dust Cap from the Redcat, make sure the [A] rotator tension knob is tightened then attach the T-Mount that is compatiable for your Camera or CCD.

Rotator


Loosen Rotator Knob part [A] to set camera to the desired angle. Please make sure the camera mount is tightened prior to this step.

Base Mounting Options

Mounting Plate [H] can be inverted for two types of mount, Arca Swiss or Vixen.

Remove screw on the bottom of the Mounting Ring, flip it over to change mount type, or slide forward/backward to change balance position. The default is to Vixen.





48mm filter Installation

Take off Redcat 51 M48 converter by untightening 3 locking screws. Install 48mm filter into the back.



REDCAT 51 ACCESSORIES

Camera Mount

Canon / Nikon / Sony α / Fuji / Pentax / Micro 4/3

Cinematagraphy







Red Dot Sight



Saddle for Guider Scope



Astrophotography



Equatorial Mount



Red Dot Sight



STC Light Pollution Filter

Visual



Erecting Prism



10mm Cat Eye