





## **PRECAUTIONS TROUBLESHOOTING** In order to have proper and safe use of the earphones, The Amp Urban X5 Earphones are not connecting with please read this user manual in detail and save it. my Device. What should I do? • Make sure that Earphones are well charged. Be aware of the following guidelines when using your Earphones: • Are the Earphones already connected to some other device? If so, please disconnect them from the device first. 1. You should adjust the volume carefully when using the • When turning the Earphones ON check if they are in Pairing Mode earphones to prevent hearing damage. the LED will blink Red + Blue. • Check the already paired devices on your Phones or PC, and if 2. Please stop using the earphones in potentially hazardous required Un-Pair and Re-Pair the Urban X5 Earphones. situations to ensure your safety. • If none of this works - Please Call the Technical Support number listed on the back. 3. Please avoid using the earphones to listen to music, make or receive calls which may cause a distraction while driving. The X5 Earphones cannot be switched ON? **4.** You should avoid turning the volume so high that you can't Please charge the earphones for at least 6–8 hours and hear anything around you. If you feel tinnitus or the volume is too high, please reduce the volume. Can I change the battery for the Earphones? **5.** You should keep water from entering the earphones, which No, this earphones uses a built-in non-detachable Li-Polymer may cause damage to the sound quality or the Earphones. **6.** Stop using the earphones if you feel obvious discomfort, irritation or have other adverse reactions. **7.** The earphones should not be stored or used at temperatures below -10 degrees or above **50 degrees** which may shorten earphones or battery life.



