

## TECHNICAL SPECIFICATIONS

<b>Technology</b>	: 2.4 GHz Wireless
<b>Connection</b>	: Plug n' Play
<b>Wireless Range</b>	: up to 10 meters
<b>Tracking Method</b>	: Optical
<b>DPI</b>	: 1200
<b>Tracking Surface</b>	: Multi Surface Tracking
<b>Multimedia Keys</b>	: 12
<b>Keyboard Layout</b>	: Compact
<b>Keyboard Battery</b>	: 2 x AAA Battery
<b>Mouse Battery</b>	: 1 x AA Battery

## TROUBLESHOOTING

- Please ensure that the batteries in both Keyboard and Mouse are installed properly and the mouse is turned on.
- Ensure that all the batteries are in working condition.
- Plug the Nano USB receiver in a different USB port.
- If the connection is lost by any chance simply re-insert the Dongle into the USB port.
- Restart your PC or Laptop with Nano receiver plugged in the USB port.

## WARRANTY STATEMENT

Amkette's Wi-Key Mini Wireless Keyboard and Mouse Combo is backed by a 1 Year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced under the following conditions:

- The warranty applies to the original purchaser. Proof of original purchase is required.
- The warranty does not cover the damage caused by misuse, abuse or improper storage.
- In no event shall Amkette be responsible for any direct, incidental, consequential or other damages of any kind.

Please contact our Customer Support Line and/or send the defective product, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return charges will be paid by us.

**Customer Care Service Centre:**

Amkette House, C-64 / 4, Okhla Phase – II, New Delhi – 110020

1800-11-9090 (Toll Free) (9:30 AM - 6:00 PM) Mon - Sat  
 +91 9312691448 (9:30 AM - 6:00 PM) Mon - Sat  
 techsupport@amkette.in

For Hassle Free Service Register your product online at [www.amkette.com/register](http://www.amkette.com/register)



# WI-KEY MINI

Slim and Silent Wireless Keyboard & Mouse Combo




## QUICK START GUIDE

## PLUG-AND-PLAY INSTALLATION


Take out the Nano USB Receiver located inside the Mouse battery compartment.

Insert the batteries into the Keyboard and Mouse.

Plug the USB receiver in to a USB port on your PC or Laptop.



## KNOW YOUR DESKTOP COMBO



### Mouse

- 1 Scrolling Wheel
- 2 Optical LED Sensor
- 3 Nano USB Receiver  
Inside the battery compartment.
- 4 ON/OFF Switch
- 5 Battery Compartment

### Keyboard


- 1 Multimedia Shortcuts
- 2 LED Indicators  
CAPS Lock  
Low battery
- 3 Battery Compartment  
Back side of the Keyboard

## WHAT'S IN THE BOX

- 1 x Wireless Keyboard
- 1 x Wireless Mouse
- 1 x Quick Start Guide
- 1 x Nano USB Receiver  
(Inside the Mouse battery compartment)

## MULTIMEDIA SHORTCUTS (KEYBOARD ONLY)

This Wireless Multimedia Combo is designed for Instant media access. Single press the multimedia keys for instant access to various media functions.



## POWER SAVING MODE

To extend the standby time and reduce battery consumption, the combo will enter into sleep mode after 2 minutes of inactivity. Click on mouse button to exit from sleep mode.

## KEYBOARD WITH SCISSOR KEYS

The Amkette Wi-Key Mini is the perfect addition to any workspace. What sets the Amkette Wi-Key Mini apart from other keyboards is its scissor keys making it thinner and lighter, more portable and easy to carry around. These keys are designed to provide a smooth and comfortable typing experience, with minimal noise and maximum accuracy.

Front

Back