

SET UP INSTRUCTIONS
3383 TWO TIER DOVES OF LOVE FOUNTAIN
3435 TWO TIER SMALL GIRL & BOY UNDER UMBRELLA FOUNTAIN
3620 TWO TIER LADY OF THE ARBOR FOUNTAIN
3650 TWO TIER GIRL HOLDING URN FOUNTAIN

Open bag containing the pump kit **P29004**. In the kit you will find:

- 1 KING 400 (400 gallon per hour pump)
- 1 1/2" plastic tee
- 1 restrictor clamp
- 1 36" long piece of 1/2" clear tubing
- 1 1/2" plastic ell
- 1 12" long piece of 1/2" kink free tubing
- 1 rubber stopper
- 1. Place pedestal on a firm level surface where fountain will remain. Place the largest shell on the pedestal.
- 2. Find the pump, 1/2" clear tubing 36" long and the rubber stopper. Attach one end of 1/2" clear tubing 36" long to pump. Place pump in pump house in center of shell and run the plug end of the electrical cord down the PVC pipe located in the pump house and down into the pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Adjust position of the rubber stopper on the power cord if necessary. Retrieve cord from under shell and place in groove in top of pedestal.
- 3. Position the largest shell on pedestal and level. To level shell, place level on top rim of the pump house in the center of shell. Level in (2) Two directions left to right and front to back. **Shim as needed**.
- 4. Find the second shell and run the 1/2" clear tubing up thru the PVC insert in the center housing of the shell. Position this shell on top of the large shell and level. To level shell, place level on center housing in center of shell. Level as stated in step #3. Cut 1/2" clear tubing 2" below the top surface of the center housing of second shell. Find 1/2" plastic tee and attach the middle connection to the end of the 1/2" clear tubing located in the center housing of the second shell.
- 5. Attach the remainder of the 1/2" clear tubing to an end connection of the 1/2" plastic tee and place tubing in the groove located in the wall of the center housing of the second shell. Cut 1/2" clear tubing about 1" past the outside wall. Find 1/2" plastic ell and attach it to the 1/2" clear tubing just outside the wall pointing down. Find the piece of 1/2" kink free tubing 12" long and attach it to the opposite end connection of the 1/2" plastic tee. Find the restrictor clamp and slip it onto the 1/2" kink free tubing about half way. Close this restrictor 3 4 clicks. This will be the connection to the statue.
- 6. Remove any excess concrete or tape from both ends of copper pipe in statue. Attach the piece of 1/2" kink free tubing located in the center housing of the second shell to the copper connection on the bottom of the statue. Leave the 1/2" kink free tubing as long as possible and wrap this tubing around inside of center housing and then connect tubing to statue. Trim 1/2" kink free tubing if necessary.
- 7. Fill shells with water and plug pump into a 110VAC GFCI protected outlet.
- 8. If fountain needs adjustment, unplug pump and close or open the restrictor clamp one click to regulate water flow to the statue until the desired result is achieved.

3383sup 4/23/07