

SET UP INSTRUCTIONS

3310 ONE TIER LARGE GIRL & BOY UNDER UMBRELLA FOUNTAIN

3565 ONE TIER LARGE PINEAPPLE FOUNTAIN

3531 52" CLASSIC RAMS HEAD FOUNTAIN

3479 52" ONE TIER LION FINIAL FOUNTAIN

3571 SPILLING LION SHELL FOUNTAIN

3639 53" CLASSICO CHERUB FOUNTAIN

Open the bag containing the pump kit P16005. In the kit you will find:

1 - 40160 (160 gallon per hour pump) 1 - rubber stopper

1 - hose clamp 1 - 8" long piece of 1/2" clear tubing

- 1. Place pedestal on a firm and level area where fountain will remain. Place a brick under one side of pedestal to help you retrieve the pump power cord. Place shell on pedestal.
- 2. Find the pump, 1/2" clear tubing 8" long, rubber stopper and hose clamp. Attach the piece of 1/2" clear tubing 8" long to the outlet side of pump with hose clamp. Place the pump in the pump house located in the center of shell. Run the plug end of the power cord down the PVC pipe located in the pump house and down thru the pedestal. Slip the rubber stopper onto the power cord with the smaller end facing away from the pump. Insert the rubber stopper snugly into the PVC pipe. Make sure the pump is seated on the bottom of the pump house. Retrieve cord from under pedestal and place in groove in bottom of pedestal. Remove brick from under pedestal.
- 3. Position shell on pedestal and level. To level shell, place the level on the top rim of the pump house in the center of the shell. Level in (2) Two directions left to right and front to back. **Shim if needed.**
- 4. Find statue or second shell or finial. On a padded surface lay the statue or second shell or finial on its back. On the bottom of the statue or second shell or finial you will see a copper pipe. Clean any excess concrete and or tape from this copper pipe.
- 5. Look inside the pump house. There you will find the piece of 1/2" clear tubing 8" long that you will connect to the statue or finial. Trim the 1/2" clear tubing to the proper length if necessary. Place a piece of padding on the pump house. Place the statue or second shell or finial on pump house. Have one person tilt and hold statue or second shell or finial and another person connect the 1/2" clear tubing to the copper connection located in the bottom of the statue or second shell or finial. Remove padding.
- 6. Place umbrella on statue.
- 7. Fill shell with tap water and plug pump into a 110VAC GFCI protected outlet. Adjust the water flow to the statue or second shell or finial using the dial type flow control located on the front of the pump until the desired result is achieved.

3310sup 6/26/08