ARDBEG 65 KEYBOARD KIT

Keys Combinations and Indicator Description

| Function | Combination | Description |
|--|-------------|---|
| Keys Combinations (Short Press) | Fn+Esc | ~` |
| | Fn+1 | F1 |
| | Fn+2 | F2 |
| | Fn+3 | F3 |
| | Fn+4 | F4 |
| | Fn+5 | F5 |
| | Fn+6 | F6 |
| | Fn+7 | F7 |
| | Fn+8 | F8 |
| | Fn+9 | F9 |
| | Fn+0 | F10 |
| | Fn+ | F11 |
| | Fn+=+ | F12 |
| | Fn + ← | Previous |
| | Fn + → | Next |
| Wireless Modes (Long Press the keys combo for 5s to enter wireless pairing mode) | Fn+Q | Bluetooth #1 |
| | Fn+W | Bluetooth #2 |
| | Fn+E | Bluetooth #3 |
| | Fn+R | 2.4GHz |
| | FN+B | Battery Level Check Each flash indicates 10% battery capacity. |

| Backlight Keys Combinations (Short Press) | Fn + Z | Backlight On/ Off |
|--|--------------|-----------------------------|
| | Fn + X | Backlight Brightness - |
| | Fn + C | Backlight Brightness + |
| | Fn + V | Backlight Speed - |
| | Fn + N | Backlight Speed + |
| | Fn + Enter | Backlight Effects Switching |
| | Fn + R-Shift | Backlight Colors Switching |
| Win Lock | Fn + Win | Long Press for 5s |
| Switch Between Mac/Windows | Fn + Tab | Long Press for 5s |
| Reset to Default | FN+Backspace | Long Press for 5s |