

# GAME 67 KEYBOARD KIT

## Keys Combinations and Indicator Description

Function	Combination	Description
<b>Keys Combinations</b> (Short Press)	Fn+Esc	~`
	Fn+1	F1
	Fn+2	F2
	Fn+3	F3
	Fn+4	F4
	Fn+5	F5
	Fn+6	F6
	Fn+7	F7
	Fn+8	F8
	Fn+9	F9
	Fn+0	F10
	Fn+~_	F11
	Fn+=+	F12
	Fn + ←	Previous
Fn + →	Next	
<b>Backlight Keys Combinations</b> (Short Press)	Fn + Z	Backlight On/ Off
	Fn + X	Backlight Brightness -
	Fn + C	Backlight Brightness +
	Fn + V	Backlight Speed -
	Fn + N	Backlight Speed +
	Fn + Enter	Backlight Effects Switching
	Fn + R-Shift	Backlight Colors Switching
<b>Win Lock</b>	Fn + Win	Long Press for 5s
<b>Switch Between Mac/Windows</b>	Fn + Tab	Long Press for 5s
<b>Reset to Default</b>	FN+Backspace	Long Press for 5s